



INSTALLATION GUIDE AND USER MANUAL

Sol-Ark 15K-2P-LV

RESIDENTIAL
NORTH AMERICA

Effective Date: July 16, 2026



TMI? Check out the 15K-2P-LV QuickStart Guide.

- The [15K-2P-LV QuickStart Guide](#) lists the essential steps for installing your Sol-Ark inverter, with links to more detailed information.
- This **15K-2P-LV Installation Manual** provides complete details about your Sol-Ark 15K-2P-LV Inverter, **MySolArk**, and more.



Read the instructions completely before operating the equipment.



- Check the utility voltage before turning ON the unit.
- Verify the inverter's programmed grid type before connecting to the utility.
- The unit is programmed in 120/240 V Split-Phase at 60 Hz by default.
- Disregarding these instructions could result in permanent damage to the unit.

Information included in this Installation Manual is current as of the Effective Date and is qualified, in its entirety, by the Disclaimer referred to below and by the terms of any applicable Limited Warranty.

Sol-Ark reserves the right to make product modifications at any time without advance notice, which may affect information included in this Installation Manual or otherwise make this information inapplicable and out-of-date.

For the latest Sol-Ark product and installation documents, visit: sol-ark.com

For errors, omissions, or suggestions, contact support@sol-ark.com

Disclaimer

UNLESS SPECIFICALLY AGREED TO IN WRITING BY SOL-ARK IN A VALIDLY EXECUTED AND DELIVERED CONTRACT:

Sol-Ark assumes no responsibility or liability for any damages, property loss, personal injury, or any adverse consequences resulting from improper use or installation of the product or the failure to adhere to the guidelines provided in this Installation Manual. Users are expressly advised to follow the instructions and guidelines outlined in the documentation accompanying the product. Sol-Ark is not liable for any damages or losses incurred as a result of, or related to, any failure to comply with, or deviations from, recommended usage, installation, or maintenance procedures. By using the product, users acknowledge their understanding of these disclaimers and agree to use the product at their own risk. Sol-Ark reserves the right to update or modify product information, specifications, and guidelines without prior notice.

This Installation Manual is provided “as is,” without charge, and is intended solely for general informational purposes without any right or presumption of reliance. Your sole and exclusive remedy for any defects, or other issues associated with, or related to, any Sol-Ark product is limited and restricted solely to the Limited Warranty provided by Sol-Ark and included in any documentation provided by Sol-Ark or otherwise made available by Sol-Ark, whether through its website or otherwise. Failure to use the most recent, commercially available version of Sol-Ark software, including firmware, may void your warranty and may cause the performance or compatibility of your Sol-Ark product to be adversely affected. You are urged, at all times, to use the most recently available Sol-Ark software, including firmware, for any Sol-Ark product, including all updates, upgrades, and other modifications of that software, including firmware, made commercially available by Sol-Ark.

This Installation Manual is not intended to, and does not, supersede any instructions or directions that you may have received from the manufacturer of any other products that you may use in combination with a Sol-Ark. Sol-Ark makes no representation regarding energy system designs within which Sol-Ark products may be used, the use or integration of third-party hardware or software, including firmware, with Sol-Ark products, or necessary compliance with local rules or regulations. Changes to non-Sol-Ark manufactured products, including to software, including firmware, or hardware components of those third-party products, may have a material effect on the performance of Sol-Ark products and could void applicable warranties or otherwise harm the performance of Sol-Ark products. To the fullest extent permitted by applicable law, Sol-Ark hereby expressly and unconditionally disclaims liability for any and all indirect, incidental, exemplary, punitive, or consequential damages.

If you are uncertain about implementing or using any of the information contained in, or made available by, this Installation Manual, you are urged not to continue with this Installation Manual and immediately to contact Sol-Ark Technical Support. This Installation Manual does not modify, extend, or change the terms of any Limited Warranty that may be applicable to your Sol-Ark products, and you should carefully consult those Limited Warranty terms to ensure that you may not be voiding or violating those Limited Warranty terms if you undertake any of the actions referred to in this Installation Manual.

Sol-Ark retains the right to final interpretation of this document and all related materials pertaining to this product. This document is subject to modifications, updates, revisions, or termination without prior notice. For the latest product information, please visit Sol-Ark’s official website. www.Sol-Ark.com

Any action related to the information included in this Installation Manual shall be governed by the internal laws of the State of Texas, United States of America, without giving effect to any conflicts of laws principles. Any action, suit, or other legal proceeding that is commenced to resolve any matter related to this Guide shall be commenced solely and exclusively in a state court sitting in Collin County, Texas (or, if appropriate, a federal court located within Collin County in the Eastern District of Texas), and you hereby consent to the personal jurisdiction of those courts. This manual is for use only with the **15K-2P-LV Hybrid Inverter**, as commercially available on the Effective Date of this Guide.

Technical Support

(USA) +1 (972) 575-8875 ext. 2

| support@sol-ark.com

Contents

Before You Start	1
Dimmer Switches	1
AC Coupling on the Load Terminal is Not Supported	1
1.Sol-Ark: At First Glance	2
Inspect shipment.....	2
What's in the box.....	2
1.1 Inverter Components and Inputs.....	3
1.2 Specifications	4
15K-2P-LV Datasheet.....	5
1.3 Connection Requirements	6
2.Installation.....	8
Backup Circuits.....	8
Single System Install	8
2.1 Mounting the Sol-Ark.....	9
2.2 Integrating Batteries	12
2.3 Battery Communication.....	14
2.4 Connecting PV Modules.....	15
2.5 Integrating a Generator.....	17
2.6 Grid Peak Shaving	18
2.7 Automatic Generator Start.....	19
2.8 Integrating Sensors and Accessories	20
2.9 Limit Sensors (CT sensors)	25
2.10 Emergency Stop and Rapid Shutdown	28
2.11 Powering up the Sol-Ark.....	30
2.12 Power Cycle Sequence	32
3.User Interface	33
3.1 LED Indicators	33
3.2 Main Menus	34
3.3 Basic Setup	37
3.4 Battery Setup.....	39
3.5 Limiter.....	42
3.6 Grid Setup	49
4.Installation Tips	51
4.1 Off-Grid Installation Tips	51
4.2 Grid-Tie and No Battery Install Tips (Passthrough mode)	51
4.3 Battery Charge Controller.....	52
4.4 Local Grid Compliance Settings	52
5.Parallel Systems	53
5.1 Before Enabling Parallel Operations.....	53
5.2 Parallel Systems Programming Sequence	56
5.3 Three-Phase Systems.....	58



6.MySolArk: Remote Monitoring	60
6.1 Setting Up MySolArk.....	60
6.2 LED Indicator and Troubleshooting.....	66
7.Wiring Diagrams	67
7.1 Sol-Ark 15K-2P-LV Standard Wiring Diagram	68
7.2 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Line Side Tap.....	69
7.3 Sol-Ark 15K-2P-LV Standard Wiring Diagram - AC Coupling in GEN.....	70
7.4 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Whole-Home Generator.....	71
7.5 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Off Grid	72
7.6 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Bypass Transfer Switch	73
7.7 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 2 Parallel Inverters 120/240V.....	74
7.8 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 3 Parallel Inverters 120/240V.....	75
7.9 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 2 Parallel Inverters 120/208V.....	76
7.10 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 3 Parallel Inverters 120/208V	77
8.Troubleshooting Guide	78
8.1 Sol-Ark Error Codes	80
9.Installation Checklist.....	81
10. GUI Screens	82
10.1 Main Menu.....	82
10.2 Basic Setup	83
10.3 Battery Setup.....	83
10.4 Limiter	84
10.5 Grid Setup	84

Important Safety Instructions

This manual provides crucial information for installing and operating the Sol-Ark 15K-2P-LV Hybrid Inverter System. Installation and maintenance procedures must be performed by qualified and authorized personnel in accordance with all applicable safety standards and system requirements outlined in this document. Sol-Ark assumes no responsibility for damage caused to a Sol-Ark product by unauthorized or unqualified personnel.

This manual is applicable to countries that comply with the certification requirements. Standards and legal requirements of other countries might differ from the specifications outlined in this manual.

Symbols in this Document

WARNING: This symbol indicates information that, if ignored, could cause serious injury, equipment damage, or death.

CAUTION: This symbol indicates information that, if ignored, could result in minor injury or equipment damage.



NOTE: This symbol indicates relevant information that is not related to hazardous situations.

Symbols on the Equipment

 **CAUTION:** Indicates risk of injury or equipment damage.

 **RISK OF ELECTRIC SHOCK:** Indicates components that present risk of electrical shock.

 **DO NOT INCINERATE:** Do not dispose of product by incineration.

 **RECYCLABLE:** Product is recyclable. Proper disposal is required.

 **REFER TO INSTRUCTIONS:** Read operating and installation instructions before proceeding.

 **cSGSUS:** SGS marking indicates NRTL product testing and certification for compliance with standards for North America and Canada.

DO NOT THROW AWAY: Proper disposal of inverters and/or batteries is required.

Notices

ATTENTION Read all instructions and cautionary markings in this document and on the equipment before installing the Sol-Ark 15K-2P-LV inverter. Failing to follow any of these instructions may also void the limited warranty provided by Sol-Ark.

All installations must conform to the laws, regulations, codes, and standards applicable in the jurisdiction of installation.

Before starting an installation, consult a local building or electrical inspector for current requirements. Local codes may vary but are adopted and enforced to promote safe electrical installations. A permit may be needed to do electrical work, and some codes may require an inspection of the electrical work. Sol-Ark is not responsible for system design or installation and makes no representations regarding system performance, reliability, or compliance with local or other codes or requirements.

When installed in the US, electrical installations are required to follow the National Electrical Code (ANSI/NFPA 70) adopted by their local AHJ (Authority Having Jurisdiction) including any local amendments.

General

WARNING: Risk of electric shock. Risk of fire. Only qualified electrical personnel should install, troubleshoot, service, or replace the equipment.

WARNING: Risk of electric shock. Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices during installation and service. Turn off all power supplying this equipment before working on or inside equipment and ensure that no charge remains in the equipment. Always use a properly rated voltage sensing device to confirm power is off. Replace all devices, covers, and doors before turning on power to the equipment.

WARNING: Inspect the equipment for damage before installation. Do not install the equipment if it has been damaged in any way.

WARNING: Do not insert foreign objects into any part of the equipment.

WARNING: Do not expose the equipment or any of its components to direct flame.

WARNING: Do not attempt to open, disassemble, repair, tamper with, or modify the equipment other than what is expressly permitted in this manual. The equipment contains no user-serviceable parts. Contact the installer who installed the equipment for any repairs.

WARNING: Do not connect life-support systems, other medical equipment, or any other use where product failure could lead to injury to persons or loss of life.

CAUTION: Do not use solvents to clean the equipment or expose the equipment to flammable or harsh chemicals or vapors. Do not allow petroleum-based paints, solvents, or sprays to contact nonmetallic parts of the equipment.

CAUTION: Do not use parts or accessories other than those specified for use with the equipment.



Installation and Use

WARNING: Risk of electric shock. Risk of fire. Only use electrical system components approved for dry locations.

WARNING: Risk of electric shock. Risk of fire. Ensure that all wiring is correct and that none of the wires are pinched or damaged.

WARNING: Risk of electric shock. Risk of fire. Before making any connections verify that the DC disconnect(s) are in the off position. Double check all wiring before applying power.

WARNING: Risk of electric shock. Improper servicing of the equipment or its components may result in a risk of shock or fire. To reduce these risks, disconnect all wiring before attempting any maintenance or cleaning.

WARNING: Risk of electric shock. Always de-energize the equipment before servicing.

WARNING: Risk of electric shock. Do not use equipment in a manner not specified by the manufacturer. Doing so may cause injury or loss of life, or damage to equipment.

CAUTION: Risk of damage. DO NOT connect the grid to the **LOAD** output terminal.

CAUTION: Risk of damage. Do not exceed **500 Voc** on any MPPT on the Sol-Ark.

CAUTION: Risk of damage or electric shock. All inverter inputs should only have one conductor connected to them.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Environmental Conditions

WARNING: This equipment is intended for operation in an environment having a minimum temperature of -40°C (-40°F) and a maximum temperature of 60°C (140°F).

WARNING: Install the equipment in a location that prevents damage from flooding. Ensure that no water sources are above or near the equipment, including downspouts, sprinklers, or faucets.

Transportation and Handling

WARNING: To protect the equipment and its components from damage when transporting, handle with care. To help prevent damage, leave all equipment in its shipping packaging until it is ready to be installed.

WARNING: Risk of physical injury or death. Use caution when using lifting equipment to move battery modules and components.

WARNING: Risk of physical injury or death. Boxed battery modules.

Requirements for Installation Personnel

All work MUST comply with local code, regulations, and industry standards. The installation of the 15K-2P-LV inverter can be completed only by qualified people with appropriate qualifications as determined by the local AHJ.

DO NOT exceed **500 Voc** on any MPPT on the Sol-Ark.

Before You Start

 Before beginning installation, review the following important considerations about your Sol-Ark Inverter.

Dimmer Switches

The Sol-Ark inverter is designed to be compatible with most standard dimmer switches; however, compatibility may vary depending on the specific dimmer model and its settings. Light flickering, reduced performance, or improper dimming may occur when used with this inverter.

AC Coupling on the Load Terminal is Not Supported

AC coupling on the inverter's critical load output terminal (**LOAD**) will no longer be supported in Sol-Ark firmware version **MCU 7.2.2.8** or newer, in combination with **COMM 1.4.5.2**.

The AC Coupling feature is limited to the **GEN** terminal due to multiple limitations and disadvantages with using the **LOAD** terminal for AC coupling:

- The Sol-Ark will not display or report AC-coupled power production of the connected inverter.
- In the event of a utility outage, the Sol-Ark may cut power to loads for several seconds to protect the battery. Longer transfer times are expected when operating off-grid.
- The inverter's **GEN** terminal cannot be used.
- Load-side AC coupling may damage either the generator connected to the grid input or the Sol-Ark inverter.

 For complete information, see the [AC Coupling Guide](#).


1. Sol-Ark: At First Glance

Inspect shipment

The box should include all items shown in the component guide. If there is damage or missing parts, immediately call Sol-Ark Technical Support at (972) 575-8875 ext. 2.


What's in the box

The Sol-Ark 15K-2P-LV system includes the following components:



Component	Description	Quantity
A	Sol-Ark 15K-2P-LV inverter	1
B	Inverter mounting cleat	1
C	Filter rings (see page 22)	10
D	CAT 5E communication cable	1
E	8mm Allen key	1
F	Temperature sensor	1
G	Wi-Fi / Ethernet antenna (dongle)	1
H	300 A (Ø1.378") Current Transformers (CT sensors)	2
I	LCD Sunshade (for outside installations)	1

1.1 Inverter Components and Inputs





Component	Name
A	PV DC disconnect
B	LCD touch screen
C	2x (200 A) battery breakers
D	Parallel RJ45 ports
E	BMS RJ45 ports (RS485 / CAN)
F	(200 A) LOAD breaker
G	Wi-Fi / Ethernet dongle
H	ON / OFF Button

Component	Name
I	Battery terminals
J	Input pinouts for sensors and accessories
K	3x MPPT inputs
L	(80 A) GEN terminal
M	(200 A) LOAD terminal
N	(200 A) GRID terminal
O	GROUND / NEUTRAL Busbars

1.2 Specifications

Dimensions



Knockout View from Bottom of Inverter

Cover thickness: 15/16in [0.937in] or 23.8mm.

15K-2P-LV Datasheet

Model: 15K-2P-LV					
Specification	Unit	Rating	Specification	Unit	Rating
PV (DC)			Battery (DC)		
Max. STC Rated PV Power	W	23,400	Compatible Technology		Lead-acid ³ or Lithium
Max. Usable Combined MPPT PV Power	W	19,500	Nominal DC Voltage	V	48
Rated MPPT Operating Voltage Range	V	150 – 425	Operating Voltage Range	V	43 – 59
Start-Up Voltage	V	125	Number of Inputs ⁴		2
Max. Input Voltage ¹	V	500	Terminal Current Rating	A	200
Max. Operating PV Input Current	A	26 (per MPPT)	Max. Charge / Discharge Current	A	275 / 275
Max. Input Short Circuit Current	A	44 (per MPPT)	BMS Communication		CANbus / RS485 / MODBUS RTU
Number of MPPT / Strings per MPPT		3/2	Charge Controller Type	3-Stage with Equalization ⁵ / CC/CV – BMS Controlled	
Grid (AC)			Backup – Off-Grid (AC)		
Nominal Voltage (L-N/L-L)	V	120/240, 120/208	Rated Voltage (L-N, L-L)	V	120/240 120/208
Nominal Frequency	Hz	50 / 60	Rated Frequency	Hz	50 / 60
Nominal Voltage Range	V	185 – 275	Max. Continuous Power	W	12,000 10,400
Nominal Frequency Range	Hz	55 – 65	Peak Surge Power (30 min)	W	13,000 11,260
Max. Passthrough Current (Grid to Load)	A	200	Peak Surge Power (10 s)	W	24,000 20,800
Max. Input Short Circuit Current (100ms)	A	120	Backup Transfer Time	ms	5
Nominal Real Power (240V)	W	15,000	Max. Load Imbalance Ratio	%	50
Max. Output Current, Batteries + PV	A	62.5	THDv	%	1.5
THDi	%	2.2			
Power Factor Adjustment Range	+/-	0.9			
Efficiency			GEN Port (AC) ²		
CEC	%	96.5	Max. AC-Coupled PV Power (240V)	W	19,200 16,640
Max	%	97.5	Max. Generator Power (240V)	W	19,200 16,640
Grid to Battery - Charge	%	92.3	Max. Current	A	80
Mechanical and Environment			Protection - Integrated		
Dimensions, H x W x D	mm (in)	838 x 494 x 306 (33 x 19.4 x 12)	PV DC Disconnect Switch — NEC 240.15	PV Arc Fault Detection — NEC 690.11	
Weight	kg (lbs.)	61.2 (135)	Ground Fault Detection — NEC 690.5	PV Input Lightning Protection	
			PV Rapid Shutdown — NEC 690.12	PV String Input Reverse Polarity Protection	
Ambient Temperature / De-rated	°C (°F)	-25 to 55 (-13 to 131) / +45 (+113)	Surge Protection - DC Type II / AC Type III		
Operating Altitude	m (ft)	> 2,000 (6561)	General		
Idle Consumption - No Load	W	90	Warranty Years	10	
Noise (@ 25°C / 77°F)	dB	< 30	Parallel Units	12	
Humidity non-condensing	%	0 – 100	Automatic Generator Start (AGS)	2-Wire Start - Integrated	
Mounting (hanging bracket included)		Wall	Communication	4G / WIFI / Bluetooth / LAN	
Enclosure Rating		IP65 / NEMA 3R	Monitoring Platform	MySolArk Mobile and Web Apps	
Cooling		Intelligent Fan	Options		
Display		LCD	Optional Accessories	4G Activation Plan, Revenue Grade Meter, Wireless CT	
Compliance and Certification					
Safety Certification	UL 1741 SB, UL 1741 SA11, UL 1741 CRD-PCS ⁵ , UL 1699B, UL 1998, CSA C22.2 107.1-16, CISP				
Interconnection Compliance	IEEE 1547.1-2020, CA Rule 21, HECO Rule 14H (SRD 2.0)				
EMC	FCC Part 15 Class B				
Listings	CEC, SGIP				

¹ The highest input voltage is based on the open-circuit voltage of the array at the minimum design temperature (See Installation Manual for more details).

² Bidirectional AC port for AC fuel generator input, AC-coupled PV input or AC load (EV Charger, etc.).

³ Lead-acid charge settings limited to: Capacity AH, Absorption V, Float V, (Equalization: V + Time).

⁴ Using only a single battery input will derate inverter and charger output capacity.

⁵ UL1741-CRD-PCS Open Loop Response Time (OLRT): Less than 10 seconds, per CA Rule 21.

1.3 Connection Requirements

Sol-Ark 15K-2P-LV Torque Values for Terminals

Do not use impact drivers to tighten any fasteners on the Sol-Ark

All wire runs should be sized to be at or below a 2.5% voltage drop at full load. Wire size must comply with your local electrical code.

AC/DC Connection Requirements


Copper wire is recommended; if you use aluminum, consult the NEC table to calculate the capacity required.

The table shows the ampacity ratings of the various connection points in the inverter's field wiring area.


Field Wiring Terminal	Description	Terminal Rating	Terminal Wire Size (min-max)	Torque [in-lb]	Torque [Nm]
I	Battery terminals	200 ADC	2/0 – 4/0 AWG	90 in-lb	10 Nm
J	Inputs for sensors and accessories				
K	MPPT inputs	44 A ISC	12 – 10 AWG		
L	GEN terminals	80 A _{AC}	2 – 4/0 AWG	165 in-lb	18.6 Nm
M	LOAD terminal	200 A _{AC}	1/0 – 4/0 AWG	165 in-lb	18.6 Nm
N	GRID terminal	200 A _{AC}	1/0 – 4/0 AWG	165 in-lb	18.6 Nm
O	Ground/Neutral Busbars		6 – 4/0 AWG	121 in-lb	13.7 Nm

Sensors and Accessories Requirements

Component	Wire Size Range	Max Distance
CT Sensor	18-23 AWG	0' – 10' [3 m]: 23 AWG included 10' – 164' [50 m]: CAT6 extendable
Communications	24 – 23 AWG	0' – 100' [30 m]: 24 AWG 100' – 400' [120 m]: 23 AWG
RJ45 Parallel Communication	CAT 5E or better	0' – 7' [2.1 m]: Included 7' – 20' [6m]: Extendable



CT Sensors (Included)



2. Installation

Backup Circuits

A. The **LOAD** connected service panel is called the **Essential Loads Panel**.

You must keep the Essential Loads Panel within the limitations of the unit:

- Grid-Tied > 48 kW = 240 V * 200 A max (passthrough).
- Off-Grid > 15kW = 240 V * 62.5 A continuous (PV & battery) | 12kW = 240 V * 50 A continuous (batteries only).

B. Verify that every load circuit power ($P=V*I$) does not surpass the limits listed above.

Single System Install


A. **FOR PARTIAL BACKUP:** Connect the output of the back-feed breaker or line side tap (depending on the point of interconnection) to the **GRID** terminal.

- An external disconnect must be installed between the interconnection and the Sol-Ark. Size the disconnect according to code.
- Connect the **LOAD** output to the Essential Loads Panel. Follow the applicable electrical code to select proper wire gauge.

B. **FOR WHOLE-HOME BACKUP:** Connect the utility grid directly to the **GRID** terminal.


- An external disconnect must be installed between the grid and the Sol-Ark. Size the disconnect according to code.
- Connect the **LOAD** output to the Main Service Panel. Follow the applicable electrical code to select proper wire gauge.

It's possible to connect a generator or an AC-coupled source (80 A max or 19,200W), such as string or micro inverters, to the **GEN** terminal of the inverter. Only one AC source can be connected to the **GEN** terminal at a time.



2.1 Mounting the Sol-Ark

1. Considering the dimensions of the inverter, find a suitable location for the system. There must be at least 6 in [15 cm] of vertical clearance and 2 in [5 cm] of side clearance for proper heat dissipation.



! Maximum heat dissipation of 525W


Under certain conditions, the National Electrical Code® specifies greater clearances. Ensure that the prescribed clearances in accordance with the National Electrical Code®, paragraph 110.26, and Canadian Electrical Code® CSA C22.1 are adhered to.

The Sol-Ark 15K-2P-LV is a NEMA 3R - IP65 enclosure that is rated for outdoor installation but can also be installed indoors.


PROTECT THE LCD SCREEN from direct exposure to UV light.

2. Use screws or anchors suitable for the support surface and capable of supporting the weight of the inverter (135 lb / 61 kg).
 - For Concrete or Masonry Mounting: Use a minimum of 5 3/8in expanding anchors (not included).
 - For Wood Frame Mounting: Use a minimum of 5 3/8in lag screws with flat washers, making sure to anchor into at least 2 framing members. (not included)
 - For Metal Framing Mounting: Use a minimum of 5 1/4in self-tapping metal screws with flat washers. (not included)
3. In case a different anchorage is required, calculate the support needed to properly hold the weight of the equipment.

Suitable Anchor for the Wall Surface




4. Mount the inverter in the optimal orientation as shown below.



5. Remove the film cover from the LCD screen.

Installing the LCD Sunshade (outside installations only)

If the Sol-Ark inverter is installed outside, be sure to attach the LCD Sunshade. This will help prevent screen damage from UV exposure.



1. Peel off the plastic film from the inverter's display surface if it's not already removed.
2. Make sure the surface is clean and dry before installation.
3. Assemble the sun-shade flap:
 - a. Insert the flap's hinge pins into the hinge slots on the base plate.
 - b. Verify that the flap opens and closes smoothly.
4. Attach the base plate:
 - a. Peel the backing from the double-sided adhesive tape.
 - b. Align the base plate with the display area just above the LED lights for DC, AC, Normal, and Alarm.
 - c. The adhesive is permanent, so confirm the alignment before applying pressure.
 - d. Press firmly to secure the LCD Sunshade.

The flap should cover the LED lights, LCD, and the blister type buttons when properly installed.

Damage to the LCD screen due to direct sunlight exposure will not be covered by warranty.

2.2 Integrating Batteries


Note: It's best practice to not mix battery banks of different makes, models, ages, or chemistries. Doing so can adversely affect performance, and in some cases it could be hazardous.

Sol-Ark 15K-2P-LV must be turned OFF while you connect the batteries.


1. Depending on the battery voltage, wire up the battery bank in the possible configurations shown below.
2. Battery breakers must be turned OFF when wiring. If your battery bank does not have internal breakers, maintain the necessary safety measures when handling.
3.  The 15K-2P-LV reaches a max battery charge/discharge of 275 A if using both sets of battery terminals. If only one set of terminals is used, the max battery charge/discharge will be limited to 160 A.

 Sol-Ark 15K-2P-LV is a **48 V_{DC} nominal system**. **DO NOT** connect the inverter to any other battery configuration. If you use 12 V batteries, you **MUST NOT** exceed 4 batteries in series. The inverter can work with any battery chemistry as long as it remains within the range of **43 V_{DC} to 59 V_{DC}**.


YES




YES



YES



NO




Series and parallel connections for complete 48 V battery bank

 **DO NOT** reverse polarity. The system will be damaged, and may void warranty.

Multi-Terminal Installation


You must use both positive and negative terminals as shown in the illustration. If you're using two sets of conductors to connect the batteries to the inverter, it is recommended to use a busbar or another suitable combiner for balanced battery charge and discharge. This configuration also ensures that you can charge and discharge at the maximum rate.



! If a single battery is capable of charging / discharging above 160 A, connect the battery to both input terminals. Otherwise, the charge and discharge rate will be limited to 160 A max. Connect batteries of the same brand, model, and chemistry to both terminals.

Important Note: Multi-system installation

! **ALL** parallel inverters **MUST** connect to a single battery bank. Otherwise, the system will **NOT** operate properly. **DO NOT** use separate battery banks in parallel systems.



! Follow all battery manufacturer-specified values to ensure proper charging and discharging.


2.3 Battery Communication

RJ-45 Configurations

The Sol-Ark 15K-2P-LV inverter achieves battery communications through a single RJ-45 port labeled **Battery Canbus**.

This port combines the RS485 and Canbus pin configurations shown.

Both **Modbus RS485** and **Battery Canbus** ports are capable of Modbus communication.



Pin	R-S485	Battery Canbus
1	RS485 B-	--
2	RS485 A+	--
3	--	--
4	--	CAN Hi
5	--	CAN Lo
6	GND	GND
7	RS485 A+	--
8	RS485 B-	--

! For a complete list of supported battery communications, see: sol-ark.com/battery-partners

Any damage caused by the improper use of the communication protocols (Canbus or Modbus) will not be covered by warranty. Modbus map is available upon request for "READ" operations only. Contact technical support to obtain the Modbus map.

External Modbus Devices

When using an external Modbus device, be sure to change the inverter's Modbus serial number to **01**. The default value for the serial number is **00**.


2.4 Connecting PV Modules

E.M.P Systems Only – Suppressor Installation


If you purchased your system with Lightning / EMP Hardening, most of the protection is within the Sol-Ark. However, additional EMP suppressors are included to protect home appliances and solar panels. The Sol-Ark 15K-2P-LV includes:

- 28 - Small suppressors
- 44 - Big suppressors

Although not critical, suppressor installation is recommended. These suppressors must be installed on the power cord, as close to the appliance as possible. Also, for solar panels, the big suppressors must clamp both conductors and must be secured with a zip tie.



a. Installation of small suppressor on appliance power cord




b. Installation of big suppressor on solar panel using a zip tie



The Sol-Ark 15K-2P-LV has 3 independent MPPTs that support up to 2 PV strings each. MPPTs can handle a maximum V_{OC} of 500 V and an I_{SC} of 44 A but will self-limit and operate at 26 A max.

- A. Max. Usable PV Power = 19.5 kW ($\pm 5\%$) | Max input power per MPPT = 6.5 kW | Max recommended input voltage per MPPT = 425 V_{OC} | Max input current per MPPT = 26 A (self-limiting).
 - ⚠ Design for a max input current of 26 A per MPPT. The inverter will self-limit beyond 26 A. If I_{SC} exceeds 44 A, damage will occur.
 - ⚠ **PV Source Circuit max voltage of 500 V_{DC} ; damage can occur with PV strings whose open-circuit voltage exceeds 500 V_{DC}**
- B. ⚠ Strings in parallel on the same MPPT must have the same designed open-circuit voltage (V_{OC}); otherwise, the system will be limited to the lowest string voltage.
 - PV1 A/B must have the same V_{OC} .
 - If the solar panels are oriented in different directions and connected in the same MPPT, there will be a loss of PV efficiency.
- C. ⚠ According to NEC Art. 690.43, exposed non-current-carrying metal parts of PV module frames, electrical equipment, and conductor enclosures of PV systems must be connected to an equipment grounding conductor. All grounding conductors and grounding electrodes should be installed according to NEC Art. 690.47 or as required by the AHJ.
- D. For ground-mounted arrays, Sol-Ark recommends installing an auxiliary grounding electrode placed near the array to ensure optimal earth-to-ground resistance of the grounding system. This auxiliary electrode must follow the requirements of NEC Art 250.54.

E. Connect the solar panel strings using either of the following configurations:



AC Coupling

The Sol-Ark 15K-2P-LV supports adding AC-coupled solar panels. The maximum solar input power can be expanded by coupling micro or string inverters into the **GEN** terminals.

A full AC-coupled solar system is not recommended because power control and monitoring is limited. Having DC-coupled modules or a combination of DC-coupled and AC-coupled solar panels is always preferred.

AC-coupled inverters need to be either UL 1741SA or UL 1741 certified. This certification confirms the inverter's ability to disconnect from the grid based on frequency; and it ensures that the Sol-Ark can safely frequency-shift to control the AC-coupled production.

! Batteries are **REQUIRED** for solar panels AC-coupled to the **GEN** terminal. The AC-coupled inverters can still produce solar power even during grid outages or in Off-Grid systems. The total AC coupling production will be monitored. See the [AC Coupling Guide](#) for more information.

Benefits of AC Coupling on GEN

- Produce solar power during grid outages
- Backup transfer time is not affected
- Frequency shifting and relays can fully isolate or disconnect the circuit if necessary

The maximum allowed AC coupling input is 19,200W.

! In Off-Grid systems, Sol-Ark uses Frequency Shift technology to shut down AC-coupled solutions when the battery is full. Grid-Tied AC-coupled solutions will always sell excess solar power back to the grid. Using the **Limited to Load** option will NOT limit production when AC-coupled.

Dark Start with AC Coupling on **GEN**

If the inverter is running off-grid and reaches battery shutdown, the inverter will close the **GEN** relay for 10 minutes to try to import AC-coupled power. This process will repeat three times per day, every 2.5 hours. If the three attempts fail, the timer will restart the next day at 8:10 AM and repeat the process.

! For dark start to succeed, AC-coupled power must exceed the load profile so it can charge the batteries.

2.5 Integrating a Generator

When needed, the Sol-Ark inverter can make use of a 240 V generator to charge the battery connected to the Sol-Ark via the GEN port.

Generators Smaller than 19.2kW > On **GEN** Terminals

1. **ONLY** Supports 120/240 V Split-Phase generators.
2. 80 A rated **GEN** terminal.
3. Less than 15% Total Harmonic Distortion (THD) recommended to avoid frequent disconnects
4. NOT compatible with:
 - 120 V Single-Phase Generators
 - 120/208 V 3-Phase Generators (2 of 3 Phases) - ⚠ Voids Sol-Ark Warranty

Generators Greater than 19.2kW > On **GRID** Terminals

1. Supports 220 V Single-Phase, 120/240 V Split-Phase, 120/208 V 3-Phase (2 of 3 phases). The correct grid type must be selected before connecting the generator.
2. ⓘ Programming **GEN Connect to Grid Input** is required: ⚙ > **Limiter** > **Other** > ☒ **GEN Connect to Grid Input**.
DO NOT use **Grid Sell** in Off-Grid systems. Potential to damage the generator. Installation of CT sensors on generator lines is only required if **Peak Shaving** will be used.

ⓘ **Weekly Gen Exercise:** If a generator has two-wire start compatibility, it will experience weekly generator tests. This test occurs at 8:00AM (local time) every Monday by default. The test takes 20 minutes to complete. The generator will start and stop automatically. The test can be disabled by specifying: **00 | 00 min** in the option **Generator Exercise Cycle Day & Time**.

Improve the Generator & Sol-Ark Compatibility

Navigate through the menus and program the following settings to improve the Sol-Ark and generator compatibility and operating range to avoid frequent disconnections.

1. Change the grid mode to General Standard: ⚙ > **Grid Setup** > **Grid Selection** > **Grid Mode**.
 - a. Tap and use the navigation arrows to cycle through the different grid modes. Choose **General Standard**.
2. Increase the frequency range of operation: ⚙ > **Grid Setup** > **Connect** > **Reconnect**
 - a. Increase **Grid Hz High** to **65 Hz**.
 - b. Decrease **Grid Hz Low** to **55 Hz**.
 - c. Replicate changes for the **Normal Connect** settings.
3. Increase the voltage range of operation:
 - a. Increase **Grid Volt High** to **275 V**.
 - b. Decrease **Grid Volt Low** to **185 V**.
 - c. Replicate these changes for the **Normal Connect** settings.

ⓘ Sol-Ark will not charge the batteries using the generator unless the **Start V** or **Start %** condition is met. Only one condition (**V** or **%**) can be modified at a time, depending on the control mode selected (**Use Batt V Charged** or **Use Batt % Charged**)


2.6 Grid Peak Shaving

! To use Peak-Shaving on a generator, the equipment **MUST** be connected to the inverter's **GRID** terminal.

Peak-Shaving helps reduce grid consumption during peak demand by utilizing battery backup power. It can also be used to prevent generator overload above a specified power threshold.

Note: Improper Peak-Shaving parameters can lead to depleting the battery bank. For more information on this feature, visit the Sol-Ark [Knowledge Hub](#).

1. Install the CT sensors on grid / generator lines L1, L2. The arrows on the CTs **MUST** point toward the grid / generator.
2. The Sol-Ark supplies power from the batteries whenever the **Power** threshold is met.



Display	Time	Advanced	Factory Reset	Parallel
☒ Solar Arc Fault ON		☐ Clear Arc_Fault		ARC parameters
☐ Gen peak-shaving				030000
				045000
				000800
				000050
				000530
				045000
				000100
				238094
☐ Grid peak-shaving		8000W		
☐ Auto detect Home Limit Sensors				CT ratio
				2000
				UPS Time
				0ms

Grid peak-shaving setting

! Grid Peak-Shaving automatically enables **Time of Use** and **MUST** be configured. To configure time-of-day-based Peak Shaving, see "Time of Use" on page 48.

! The inverter has not been PCS tested or certified for Zero Export functionality on three-phase 120/208 V operation.

Limitation for Three-Phase Configurations on Parallel Systems

For three-phase configurations using multiple inverters, Grid Peak Shaving is not supported on any Sol-Ark *residential* inverters, including the 15K-2P-LV. If you require Grid Peak Shaving for multiple inverters, Sol-Ark offers commercial three-phase hybrid inverters.


2.7 Automatic Generator Start

1. ☒ **Gen Charge** is used when the generator is connected to the **GEN** terminal.

- Start V or Start %** is the set-point/condition that must be fulfilled to **automatically start** the generator.
- To charge from the **GEN** source, check the ☒ **Gen Charge** box.
-  Batteries will charge from a generator until the battery bank accepts 5% of its programmed capacity in Amperes (A). This is equivalent to around 95% of the state of charge (SOC).

2. ☒ **Grid Charge** is used to charge the battery from the **GRID** source (either the Grid or a generator).

- Start V or Start %** is the set-point/condition that must be fulfilled to start the battery charge from the **GRID** source. This will auto-start a generator as well.
- To charge the battery from the **GRID** source, ☒ **Grid Charge** must be selected:  > **Battery Setup** > **Charge**.
-  From utility grid: the batteries will be charged to 100% SOC.
-  From generator: the batteries will charge until the battery bank accepts 5% of its rated capacity in Amperes (A). This is equivalent to around 95% SOC.




If **Time of Use (TOU)** is enabled, a time to charge from that **GRID** or **GEN** source **MUST** be designated. Be sure to check the ☒ **Charge** box for the time intervals needed; otherwise, the generator will not start automatically even if the **Start V** or **Start %** condition is met.


To use the automatic generator start feature, the generator must have a 2-wire start component, and it must be connected to ports 7 and 8 (see "2.8 Integrating Sensors and Accessories" on page 20). Consult the generator manufacturer to find out if your generator has a compatible 2-wire start feature.

Gen Charge / Grid Charge A

A is how many amps (**DC**) are supplied to the battery from a generator. Adjusting and limiting the **GEN** or **GRID A** value will ensure that small generators are not overloaded when charging the battery bank.

If you're connecting more than one Sol-Ark in parallel, multiply the **Gen** or **Grid A** value by the **# of Sol-Ark inverters** to get the actual current (A) that will go into the battery bank.

2.8 Integrating Sensors and Accessories



Inverter pinouts for sensors and accessories


Sensors and accessories connect to these inverter pinouts:

1 & 2: Battery temperature sensor	Not polarity sensitive. Used for voltage compensation.
+3 & -4: CT1	Current transformer (CT) inputs
+5 & -6: CT2	Current transformer (CT) inputs
7 & 8: Gen Start Relay	Normally open relay for generator two-wire start
9 & 10	Not in use
B & B: Emergency Stop	Normally open dry contact for emergency stop
+, -	Not in use
+15 -16	12 V power supply for RSD transmitters (100 mA max, 12 V_{DC}, 1.2 W)

Temperature Sensor


1. Place the sensor between two batteries as shown below.
2. Secure with tape and place away from the battery terminals to prevent overheating.
3. This sensor has no polarity. The temperature sensor helps perform voltage charging adjustments and capacity calculations due to changes in temperature.

! Lithium Batteries **DO NOT** require our external temperature sensor.



Wi-Fi / Ethernet Antenna (Dongle)

- Remote monitoring and software updates require an internet connection through the Wi-Fi / Ethernet Antenna (Dongle).
- Compatible with Wi-Fi or Ethernet connections.



Wi-Fi dongle (antenna)

BMS Port (CAN/RS485)


- This port is used to set up a Lithium Battery in closed-loop communication with the Sol-Ark 15K-2P-LV. See the [Low Voltage Battery Integration Guide](#) on the Sol-Ark website.
- You must use an RJ-45 connector.
- Only use the **CAN** port for battery BMS communications (the **CAN** port supports both Canbus protocol and Modbus protocols).

GEN Start Signal (Two-wire start)

- Gen start relay: pins 7 & 8.
- The signal comes from a normally open relay that closes when the generator **"Start"** condition is met.


Battery Toroids

Install the included toroids on the battery conductors according to the diagram below. Make sure that both (+) and (-) wires pass through both toroids simultaneously. When there are 4 wires, all conductors must go through the toroids as shown.



Installing Filter Rings




If your inverter includes filter rings, follow the installation steps on the next page. The Sol-Ark 15K-2P-LV system includes these filter rings:




- A 2 small white filter rings** for the BMS and Meter (outside diameter 33mm, inside diameter 20mm)
- B 3 small black filter rings** for wiring area (outside diameter 30mm, inside diameter 20mm)
- C 1 medium black filter ring** for the load and/or generator (outside diameter 65mm, inside diameter 45mm)
- D 1 medium black filter ring** for grid port (outside diameter 59mm, inside diameter 35mm)
- E 2 large black filter rings** for battery (outside diameter 84mm, inside diameter 48mm)
- F 1 small black filter ring** for PV terminal (outside diameter 52mm, inside diameter 35mm)

Filter Rings A (2 small white filter rings)

- a. Pass the **BMS 485/CAN** communication line through filter ring A and wrap it around four times.




- b. Pass the **Meter-485** communication wires through the other filter ring A and wrap it around four times.



Filter Rings B (3 small black filter rings)

For each of the three filter rings B: wrap the wires around twice, then thread the end of the wires through the filter ring. Do this for each of these components:







- Batt_Temp_in** (1,2), **CT_L1_in** (3,4), **CT_L2_in** (5,6): Wrap these wires around one filter ring B.
- Gen_Start_relay** (7,8): Wrap these wires around one filter ring B.
- RSD_input** (B, B, +, -), **RSD 12V_out** (15 +, 16-): Wrap these wires around one filter ring B.



Filter Ring C (1 medium black filter ring--outside diameter 65mm)


Filter ring C is the generator and load port ring. Follow the steps that apply to your setup.

- If using the GEN and LOAD port:** pass all 6 GEN and LOAD conductors through filter ring C
- If using only the GEN port:** pass GEN and LOAD conductors through filter ring C
- If using only the LOAD port:** Pass all LOAD conductors through filter ring C




Step 4: Install Filter Ring D (1 medium black filter ring--outside diameter 59mm)

Pass GRID conductors (L1, L2, Neutral) through filter ring D, as shown below.




Step 5: Install Filter Rings E (2 large black filter rings)

Pass one positive and one negative battery power cable through filter ring E, then wrap them around the ring one time. Do the same for the other set of conductors.




Step 6: Install Filter Ring F (1 small black filter ring)

Thread the wires of the PV terminal through Filter Ring F.



2.9 Limit Sensors (CT sensors)

The CT sensors (or limit sensors) enhance system capabilities by enabling the use of the system work modes known as **"Limited Power to Home"** (Meter Zero) and **"Grid Peak-Shaving."** The CTs will measure and calculate total load demand which the Sol-Ark 15K-2P-LV will then use to accurately supply and offset all existing loads (Meter Zero).




! Off-Grid systems do not require CT sensors unless "Grid Peak-Shaving" is used.

Installing CT Sensors

- Install sensors on incoming electrical service wires (L1, L2, and L3 if the system is 3 Φ).
- Embossed arrows on the sensors must point toward the grid.

! If the system is 3 Φ , the arrows must point toward the inverter(s).

- To ensure proper fit, check incoming wire diameters (grid or generator). If the sensors are too small, you can call Sol-Ark Sales to purchase bigger CTs at: +1-972-575-8875 ext. 1 or sales@sol-ark.com
- **Limited Power to Home** (Meter Zero) and **Grid Peak Shaving** require CT sensors.
- See "3.5 Limiter" on page 42 for more information about the different work modes.
- See Section 7, "Wiring Diagrams" on page 67 for more information on CT installation.




CT Sensor Size

- The Sol-Ark 15K-2P-LV includes two **300 A** CT sensors (Ø1.378").
- Sol-Ark offers large **200 A** (Ø0.945") and extra-large **600 A** (Ø1.976") CT sensors upon request. Contact Sol-Ark Sales at +1 (972) 575-8875 or sales@sol-ark.com to purchase larger CT sensors.
- Default Sol-Ark CT ratio is 2000:1

Unless authorized, **DO NOT** change CT Ratio or warranty will be voided

Wiring the CT sensor

- Connect CT1 of line L1 to pins 3 (white) & 4 (black).
- Connect CT2 of line L2 to pins 5 (white) & 6 (black).
- Keep the wires twisted (white-black) throughout the connection.
- If the wires need to be extended, use CAT 6 (shielded) cable to make an extension.



CT Sensors for 120 V/240 V Split-Phase

- Each inverter includes 2 CT sensors.
- Only one pair of CT sensors must be wired to the designated "Master" inverter.

! CT sensors are essential for multi-Sol-Ark systems as "Limited Power to Home" mode is highly recommended.

CT Sensors for 120 V/208 V Three-Phase

- Install CT1 on L1 and CT2 on L2 of inverter 1. Program inverter 1 to Master, Phase A.
- Install CT3 on L3 of inverter 2. Program inverter to be Master Phase B. Use pins 5 and 6 for CT3.

! CT sensors on 3-Phase systems **MUST point in the opposite direction** (toward the inverters).

Configuring Automatic CT Limit Sensors

This function **REQUIRES** batteries and 120/240 V grid to auto detect and auto correct CT orientation. AC-coupled inverters need to be **OFF** during the detection test.

If this test is done with connected AC-coupled systems, a factory reset of the Sol-Ark must be performed.

1. Install the CT sensor as described on page 25.
2. A battery connection and grid power are required before starting the automatic configuration:
⚙️ > **Basic Setup** > **Advanced** > ☒ **Auto detect Home Limit Sensors**
3. Wait at least 10 to 15 seconds while the inverter performs the test. The inverter will alternate the current distribution in all lines, determining the correct orientation of the sensor.



- In “**Limited power to Home**” mode (no Grid Sell), HM values will read close to zero (0). Be aware that all sensors have a 3% error.
- To avoid selling power to the utility use **Zero Export Power** equal to or greater than 20W.
- Buying power from the grid will display positive (+) HM values, while selling to the grid displays negative (-) HM values.

2.10 Emergency Stop and Rapid Shutdown

Note on optimizers: Some third-party module level optimizers may not be compatible with the Sol-Ark inverter. If you're using optimizers, consult a qualified installer for an alternative method for optimization, such as microinverters or another rapid shutdown solution.

Powering the Rapid Shutdown Transmitter


There are two ways to set up your transmitter for rapid shutdown, depending on the rated power draw of the RSD transmitter. Check the manufacturer's documentation to determine how much amperage your transmitter draws.

Option 1: RSD draws up to 100mA

The (B, B) emergency stop pins of the Sol-Ark 15K-2P-LV are an ordinarily open contact that triggers rapid shutdown (RSD) when closed. RSD will cut all power, including the Sol-Ark's internal power supply and stop all AC outputs. The internal 12 Vdc (-3%) power supply of the Sol-Ark (pins 15 & 16) will disconnect any RSD transmitter that will then shut down all solar panels when the emergency stop button is pressed.

- Emergency stop button connects to (B, B) pins of the Sol-Ark
- RSD transmitter connects to pins 15 & 16 (12 Vdc power supply)

! Transmitters placed inside the user area of the Sol-Ark can cause interference.



RSD Warning!


The Built-in 12 Vdc power supply of the Sol-Ark 15K-2P-LV (Pins 15 & 16) is rated for 100mA (1.2W). Do not exceed! If you are unsure of the current (A) rating of the transmitter, contact the manufacturer before connecting.

Option 2: RSD transmitter draws greater than 100mA

If a transmitter is equal to or more than the maximum 100mA limit, it can still be integrated into the Sol-Ark inverter through an external power supply connected to the **LOAD** output.

Pressing the **e-stop** button will disconnect all AC outputs, cutting power to the **LOAD** service panel, which will initiate rapid shutdown.

Here's an example.



Rapid Shutdown Product Recommendations

These recommended rapid shutdown solutions are readily available on the market:

- Tigo TS4-A-S
- Tigo TS4-A-O
- NEP PVG-Guard
- APsmart RSD S-PLC
- APsmart RSD-D

2.11 Powering up the Sol-Ark

! TURN ON the inverter with at least one power source: Battery, PV, or Grid.


1. Check the voltage of the battery bank

- The battery voltage must be between $43 V_{DC}$ - $59 V_{DC}$.
- If applicable, turn **ON** internal switches of the batteries. Measure individual voltages.
- Verify that the voltage of the battery bank at the Sol-Ark terminals is adequate.

! **DO NOT** reverse polarity. **DO NOT** turn **OFF** battery disconnect if any current is flowing into or out of the battery.

2. Check the voltage of each PV input circuit

- !** Input voltage must not exceed $500 V_{DC}$.
- Input voltage must be above the startup voltage of $125 V_{DC}$.
- Do not ground PV+ or PV-.
- Verify polarity in each PV string. Backward polarity will measure 0 Vdc by the Sol-Ark and will cause long-term damage.
- !** PV power alone can power the LCD screen but cannot operate the inverter. The inverter requires **grid** and/or **batteries** to operate, otherwise an "OFF" message will appear.
- PV DC disconnect switch on the side of the inverter will turn the PV ON or OFF.



3. Check GRID input voltage


- Use the **GRID** terminals to measure AC voltage with a multimeter.
- Measure line (L) to neutral (N) voltages on **GRID** terminals. Ensure $120 V_{AC}$ on all phases.
- Measure line (L) to line (L) voltages on **GRID** terminals. Ensure $240 V_{AC}$. (If voltage reading is close to 220 V or 210 V, verify if grid is Single-Phase or Three-Phase instead).
- Verify that voltage between Neutral and Ground is $0 V_{AC}$.
- Verify that voltage between **GRID L1** and **LOAD L1** is $0 V$. Do the same for L2.

4. Power ON the Sol-Ark 15K-2P-LV | Single Inverter Systems

Follow the instructions below for your power source.

4.1 Powering up from a Battery bank

- A. Turn **ON** the battery breaker(s).
- B. **PRESS** the power button to the **ON** position.
- C. **PROGRAM** the settings on the inverter according to your **Battery** and **GRID** type.
The unit is programmed in **Split-Phase 120/240 V** by default.
- D. Wait for the “**Normal**” LED indicator to turn on. This may take a few minutes.
- E. Turn **ON** the PV DC disconnect switch. Wait for **DC** LED indicator to turn on.
- F. Turn **ON** the external **GRID** disconnect. Wait for **AC** LED indicator to turn on.
- G. Turn **ON** the internal **LOAD** and external **GEN** breakers.



4.2 Powering up from the Grid

- A. Turn **ON** the external **GRID** disconnect and wait for “**AC**” LED indicator to turn on. Do **NOT** press the power button yet.
- B. **PROGRAM** the settings on the inverter according to your **GRID** type. The unit is programmed in **Split-Phase 120/240 V** by default.
- C. **PRESS** the power button to the **ON** position.
- D. Turn **ON** the PV DC disconnect switch. Wait for the “**DC**” LED indicator to turn on.
- E. Wait for the **Normal** LED indicator to turn on. This may take a few minutes.
- F. Turn **ON** the internal **LOAD** breaker.



- If your system does not have a PV source, you can skip steps D and E. Under these conditions, the inverter will operate in pass-through mode only.
- If no battery bank is connected to the inverter, the **GEN** port will be disabled as it requires the battery **SOC%** to open and close the internal **GEN** port relays.

5. Power ON Sol-Ark 15K-2P-LV | Parallel install

5.1 Powering up from a Battery bank

- A. Turn **ON** the battery breakers for all of the units, the order does not matter in this step.
- B. **PRESS** the power button to the **ON** position in all units; the order of the units is not important.
- C. **SELECT** as the "**Master**" unit one of the inverters to **PROGRAM** the **GRID** type and **Battery** settings. By default, the units are set to **Split-Phase 120/240 V**. The parallel communication will copy the settings from the "Master" unit to all "Slave" units. It's not necessary to program GRID and Battery settings in each unit.
- D. **SET the DIP switches** as shown in "5.1 Before Enabling Parallel Operations." **PROGRAM** each inverter for parallel operation as shown in "5.2 Parallel Systems Programming Sequence" on page 53.
- E. **VERIFY** the **GRID** and **Battery** parameters are properly transferred from the "Master" unit to the "Slave" units. Wait for the "**Normal**" LED indicator to light up on each unit. This may take a few minutes.
- F. Turn **ON** the PV DC disconnect switch for all units. Wait for "**DC**" LED indicator to turn on for all units.
- G. Turn **ON** the external **GRID** disconnect/breakers. Wait for "**AC**" LED indicator to turn on for all units.
- H. Turn **ON** the internal **LOAD** and external **GEN** breakers.

5.2 Powering up from the Grid

- Parallel communication CANNOT be established without a Battery Bank. In these systems, it's not necessary to activate parallel operation for the inverters.
- The powering-up process is the same as for single inverter systems described in "4.2 Powering up from the Grid" on page 31.

2.12 Power Cycle Sequence

Single Inverter Systems


1. **TURN OFF** all AC breakers and disconnects (**GRID**, **GEN**, and **LOAD**).
2. **TURN OFF** the built-in PV DC disconnect switch on the side of the inverter.
3. **PRESS** the power button, making sure it is in the **OFF** position. The LCD screen will turn off after a few seconds.
4. **TURN OFF** the battery breakers.
5. Wait a moment (~1 min) to make sure the inverter is completely de-energized.
6. Make sure that the Sol-Ark is properly connected to the batteries, solar panels, **GRID**, **GEN**, and **LOAD**.
7. Reverse the steps to turn **ON** the Sol-Ark.

Parallel Installation

1. **TURN OFF** all AC breakers/disconnects (**GRID**, **GEN**, and **LOAD**) for all units. Start with the "Master" units and then proceed to the "Slave" units.
2. **TURN OFF** the built-in PV DC disconnect switch on the side of the inverter. Start with the "Master" units and then proceed to the "Slave" units.
3. **PRESS** the power button, making sure it is in the **OFF** position. Start with the "Master" units and then turn off the "Slave" units.
4. **TURN OFF** the battery breakers. The order of the units in this step is not important.
5. Wait a moment (~1 min) to make sure the inverter is completely de-energized.
6. Make sure that the inverters are properly connected to the batteries, solar panels, **GRID**, **GEN**, and **LOAD**.
7. Reverse the steps to turn **ON** the inverters. When powering ON, always start with the "Slave" units and finish with the "Master" units.

3. User Interface

3.1 LED Indicators



DC	AC	Normal	Alarm
Green > DC Solar Panels connected and providing voltage.	Green > Grid is connected and providing voltage.	Green > Sol-Ark is fully energized* and inverting power.	Red > Alarm state. Check the alarms menu. Home Screen > ⚙ > "System Alarms"
OFF > Minimum MPPT voltage not met, wrong polarity or no PV _{DC} .	OFF > Grid voltage out of range or Off-Grid system.	OFF > Not fully energized*, in fault state or in passthrough mode.	OFF > No alarms / error codes / setting change notifications




*Fully energizing the unit constitutes at least:
a. DC Solar panels AND Grid
OR
b. Batteries only


3.2 Main Menus



Main Screen



Details Screen



- ⚠ MPPT voltages **MUST NOT** exceed 500 V.
- Battery temperature will measure 25°C by default if the battery sensor is not connected.
- ⚠ DC Temp: Sol-Ark 15K-2P-LV does not have internal DC temperature sensors. You can ignore the temperature reading.
- AC Temp: Internal AC conversion side temperature. Output derating occurs at 75°C and above; shutdown occurs at 82°C.
- "Grid" column measures: Voltage, Current, Power, and frequency of the utility grid.
 - When exporting power to the grid, watts display as negative (-)
 - If buying from the Grid, Watts = positive (+)
 - HM: power measured by the external CT sensors. (L1, L2).
 - LD: power measured by the internal sensor on GRID terminal. (L1, L2).



Opposing "Grid" or "HM" values indicate an incorrect installation of the CT. See "Wiring Diagrams" on page 67.

PV Power Generation Graph

- Displays power production over time for the PV array.
- Use up/down arrows (↑, ↓) to navigate between days.
- Month view/ year view/ total production.

Grid Usage Graph

- Displays power drawn from grid (+) / sold to the grid (-).
- Values above the line indicate "power bought" from the grid.
- Values below the line indicate "power sold back" to the grid.
- This view can help to determine when the peak power is used from the grid.

System Setup Menu

System Setup 

08/14/2025 03:05:27 PM Thurs.

Basic Setup

System Alarms

Battery Setup

Only with BMS Lithium Mode


Li-Batt Info

Limiter

Grid Setup

- ID: #####
- COMM: ####
- MCU: Ver####

3.3 Basic Setup



The screenshots show the following configuration options:

- Brightness:** A slider bar for adjusting screen brightness.
- Auto Dim:** A checkbox to enable automatic screen dimming, with a value of 600S.
- Beep:** A checkbox to enable or disable the alarm sound.
- Time:** Fields for Year (2021), Month (10), Day (26), Hour (03 PM), Minute (04), and Second (15).
- Seasons:** A checkbox to enable seasonal settings, with fields for Season 1, Season 2, and Season 3 (Start M-D and End M-D).
- Advanced:**
 - Solar Arc Fault ON:** A checkbox to enable solar arc fault protection.
 - Clear Arc_Fault:** A button to clear the arc fault.
 - ARC parameters:** A list of parameters including 030000, 045000, 000800, 000050, 000530, 045000, 000100, and 238094.
 - Grid peak-shaving:** A checkbox to enable grid peak-shaving, with a value of 8000W.
 - Auto detect Home Limit Sensors:** A checkbox to enable automatic detection of home limit sensors.
 - CT ratio:** A field for the CT ratio, set to 2000.
 - Factory Reset:** A checkbox to reset the system to factory defaults.
 - System selfcheck:** A checkbox to enable system self-checks.
 - Lock out all changes:** A checkbox to lock out all changes.
 - Test Mode:** A checkbox to enable test mode.
 - Lock Grid Charging & Limited:** A checkbox to lock grid charging and limit power.
- Parallel:**
 - Parallel:** A checkbox to enable parallel operation.
 - Master/Slave:** Radio buttons to select Master or Slave mode.
 - Modbus SN:** A field for the Modbus serial number, set to 01.
 - A/B/C Phase:** Radio buttons to select A Phase, B Phase, or C Phase.
 - Meter->Grid:** A checkbox to enable meter-to-grid functionality.
 - Meter2->Grid Tie:** A checkbox to enable meter2-to-grid tie functionality.
 - Meter2->Load:** A checkbox to enable meter2-to-load functionality.
 - MeterSelect:** A dropdown menu to select the meter type, currently set to "No Meter".
 - WattNode:** A checkbox to enable WattNode functionality.

Display

Brightness: Brightness adjustment (+, -).

Auto Dim: Must be enabled at all times to validate the warranty of the LCD screen.

Beep: Enable / disable the alarm sound.

Time

Time Sync: Automatically syncs with the internet for daylight saving time changes. (Enabling **Time sync** is recommended).

Seasons: Setup and customize the seasons for TOU.

Advanced

Solar Arc Fault ON: Enables the Arc fault detection algorithm on the MPPTs.

Clear Arc Fault: Command to clear an Arc Fault.  It must be done manually every time the system detects an F63 Arc Fault alarm. See section "8.1 Sol-Ark Error Codes" on page 80 for more detail.

Gen Limit Power: Limits the power drawn from the **GEN** AC source. The inverter will reduce battery charge when value is reached.

Load Limit Power: Sets a limit to the total **LOAD** output power. The max output power of the inverter is programmed by default.

Grid-Peak Shaving: Sets a **GRID** consumption threshold that allows use of battery backup power during peak demand. External CT sensors are required. Peak shaving can be used on a generator provided it is wired to the **GRID** terminal.

Auto detect home Limit Sensor: Detects and auto-corrects the polarity of the CTs. See "2.9 Limit Sensors (CT sensors)" on page 25 for details.

CT Ratio: Specifies the transformation ratio of the CT. Default value of 2000:1
DO NOT change or warranty will be voided.

UPS Time: Backup transfer time to essential loads upon grid disconnection. Default value of 5 ms.

Factory Reset

Restrictions: Changes to these settings must be previously authorized by Sol-Ark technical support agents.

Parallel


Parallel: Enables communications between parallel inverters. "Master" and "Slave" inverters must be programmed.

Modbus SN: Identification number for each system configured in parallel (1,2,3,4, n).

Phase: When dealing with a 120/208 V 3-Phase system, there must be a "Master" unit responsible for each phase (A, B, C).

 See section 5, "Parallel Systems" on page 53 for more information.

3.4 Battery Setup



The screenshots show the following settings:

- Batt Setup (Batt Tab):** Batt Capacity: 400Ah, Max A Charge: 275A, Max A Discharge: 275A, TEMPCO: -0mV/C/Cell, Use Batt V Charged: ☐, Use Batt % Charged: ☒, No Battery: ☐, BMS Lithium Batt: ☐ 00, Activate Battery: ☒.
- Batt Setup (Charge Tab):** StartV: 49.0V, Float V: 55.9V, Absorption V: 55.9V 1h, Equalization V: 55.9V, 30 Days, 1.0 hours, Mon 08 :00 4 min, Gen Charge: ☐, Grid Charge: ☒, Gen Force: 1440min, Gen max run time: CANCEL.
- Batt Setup (Discharge Tab):** Shutdown: 46.0V 20%, Low Batt: 47.5V 35%, Restart: 53.0V 50%, Batt Empty V: 47.0V, Batt Resistance: 8mOhms, Batt Charge Efficiency: 99.0%, BMS_Err_Stop: ☐.
- Batt Setup (Smart Load Tab):** Use gen input as load output: ☐, On Grid always on: ☐, Smart Load OFF Batt: 51.0V 80%, Smart Load ON Batt: 54.0V 90%, Solar Power (W): 500W, For AC Coupled input to Gen: ☐, High Frz: 62.00Hz, AC couple on grid side: ☐.

Batt

Batt Capacity: Specifies the capacity of the battery bank. Value expressed in Amp Hour (Ah).

! **Batteries in series:** Voltage adds up (V).

! **Batteries in parallel:** Capacity adds up (Ah).

Max A Charge: Sets the maximum charge current (A) rate to the batteries when charged from solar power > 275 A max allowed.

! **For Lead-Acid batteries:** If the manufacturer does not specify rated charge amps, use 20% - 30% of battery capacity as Max A Charge.

Max A Discharge: Sets the maximum discharge current (A) rate from the batteries to > 275 A maximum allowed.

For Off-Grid systems, the battery bank will discharge 120% of this value for a 10 second surge before the inverter faults to prevent battery damage.

TEMPCO: Temperature coefficient used in conjunction with the battery temperature sensor to adjust optimal voltages for lead-acid batteries.

! Lithium batteries do not require a TEMPCO setting (-0 mV/C/Cell).

Use Batt V Charged: Displays battery charge in terms of voltage.

Use Batt % Charged: Displays battery charge in terms of %. The inverter uses algorithms measuring power in and out to estimate a true value for state-of-charge %. It compensates for aging batteries.

No Battery: The **No Battery** option **MUST** be selected if there is no battery. A power cycle sequence is **REQUIRED** when selecting this option. See "2.12 Power Cycle Sequence" on page 32 for power cycle instructions.

BMS Lithium Batt: Allows closed-loop communication with the tested batteries included in Sol-Ark's *Battery Integration Guide*. See www.sol-ark.com/battery-partners for complete list of compatible batteries.

Activate Battery: This option **MUST** be selected if the system has batteries, especially **Lithium** batteries.

Charge

Float V: Lower steady voltage at which the battery is maintained after being fully charged.

Absorption V: Constant voltage used to charge the battery.

- Absorption will stop at 98% of the capacity of the battery bank and then drop to the Float setpoint.
- Example: A 400 Ah battery will stop charging when it reaches 392 Ah.

Equalization V: Voltage that the system uses to generate a calculated overcharge, utilizing a higher voltage or equal to the absorption to remove the generation of sulfates in batteries. Used to balance internal cells.

! Most Lithium batteries do not need to equalize.

Days: The period between equalization cycles.

Hours: The period taken to equalize batteries.

! If **Hours** is set to **0** hours, the system will not equalize batteries.

Gen Charge: Uses the **GEN** input of the system to charge the battery bank from a generator.

- **Start V:** Voltage at which the system will AutoStart a generator to charge the battery.
- **Start %:** Percentage S.O.C (state of charge) at which the system will AutoStart a generator to charge the battery.
- **A:** Maximum rate of charge of the batteries from the generator (DC amps).

Grid Charge: There are two scenarios in which this option is used:

- **Grid connected to Grid input:** The inverter will limit the charge rate to the set value in "A" and the battery will charge to 100% SOC.
- **Generator connected to Grid input:** It will be necessary to select ☒ **GEN connect to Grid input**. The system will use **Start V**, **Start%** and **A** conditions to charge the battery and stop charging at 95% SOC.

! Adjustable upper limit if Time of Use is enabled.

Gen Exercise Cycle (Day & Time): Set a weekly generator exercise schedule. (Day of the week/time/duration length).

Gen Force: Test function for generator auto-start. Enable and press OK to close normally open relay (pins 7,8) and force the generator on. Disable and press OK to disengage. The generator will not provide power during this test if grid power is available.

! The gen must be in automatic mode if applicable and must have a two-wire start (dry-contact, normally open) connected to the Sol-Ark. To disable the Gen exercise, adjust the time duration to 0 min.

Discharge

Shutdown: Battery voltage or % at which the inverter will shut down to protect the battery from an over discharge situation (battery symbol on the home screen will turn red).

Low Batt: Low battery voltage or % (battery symbol on the home screen will turn yellow). Stopping point for TOU.

Restart: Battery voltage or % at which AC output will resume after previously reaching "shutdown."

Batt Resistance: Internal resistance of mOhms from the battery bank. Used in % SOC batt calculations.

Batt Charge Efficiency: Value provided by battery manufacturer. Used in % SOC batt calculations.

Batt Empty V: Sets the empty voltage and associates this voltage to 0% charge. This value determines the lowest % SOC limit.

BMS_Err_Stop: Enables system stop when there is loss of battery communications.

! Continuous **GEN** input/output of 80 A. DO NOT EXCEED.

Smart Load

- This mode uses the **GEN** input as a load output that delivers power when the battery exceeds a user programmable threshold or when the Sol-Ark is connected to the grid.
- When ☒ **Use gen input as load output** is enabled, the **GEN** input terminal turns into an output to power high-power loads such as a water heater, irrigation pump, AC unit, pool pump, or any other loads.
- When ☒ **On Grid always on** is enabled, the **GEN** terminal will always output power as long as the grid is connected, regardless of battery charge.

Smart Load OFF Batt: Battery voltage or % at which the **GEN** terminal will stop outputting power.

Smart Load ON Batt: Battery voltage or % at which the **GEN** terminal will start outputting power.

Solar Power (W): Amount of PV production needed before **GEN** terminal starts outputting power.

AC Coupling Settings - (For AC-coupled Input)

- Grid-tied systems with AC-coupled solar arrays must have ☒ **Grid Sell** enabled. Make sure that you are allowed to sell back to the grid.
- To use the **GEN** terminal as an AC coupling input for micro inverters or string inverters, check the box ☒ **For AC-coupled Input to Gen**
- In off-grid systems, the Sol-Ark will use frequency shifting to control the AC-coupled solution based on the battery SOC. The meaning of **Smart Load OFF Batt** and **Smart Load ON Batt** will change in this mode:


Smart Load OFF Batt: The % SOC at which the AC-coupled inverters turn OFF.

ⓘ 90% recommended.

Smart Load ON Batt: The % SOC at which the AC-coupled inverters turn ON.

ⓘ 80% recommended.

3.5 Limiter



The Sol-Ark 15K-2P-LV inverter will simultaneously utilize different available power sources to satisfy load demand in the electrical service panels (essential loads panel/main service panel). The following work modes let you determine how generated power is utilized.


Grid Sell

Grid Sell: The inverter will produce as much power as it has available from PV array according to the value programmed here. The maximum power that can be sold to the grid is 15,000W. The **Grid Sell** value acts as a limit on the amount of power, including any power from an AC-coupled source, that will be exported (sold) to the grid.

Note: The **Grid Sell** control cannot limit AC-coupled PV sources. If the AC-coupled power source meets or exceeds the **Grid Sell** value, all other sources, such as MPPT and battery, are curtailed in order to not exceed the programmed **Grid Sell** value.

General description

- This mode allows your inverter to sell back to the grid all the excess power generated from the PV arrays without limitation.
- The inverter will only show loads connected to the **LOAD** terminal.
- The inverter will measure all power in / out of the **GRID** terminal as grid consumption or grid sell back.



Limited Power to Home

! This work mode **REQUIRES** batteries

Limited Power to Home (Meter Zero)


This mode limits the energy produced by the inverter to satisfy the home demand (essential loads panel + main service panel). In this mode, the inverter delivers power to the **LOAD** terminal (essential loads panel) + the **GRID** terminal (main service panel).

CT sensors **MUST** be installed. These sensors measure load consumption in the main service panel to offset total load demand and prevent selling to the utility. This system work mode is useful for users who don't have a permit to sell back.

See "2.9 Limit Sensors (CT sensors)" on page 24 for instructions on installing external CTs.

General description

1. Power is delivered to the whole home without selling the excess solar back to the grid (this is required if there's no permit to sell back from the utility company).
2. External CT sensors are **required** for proper operation of this system work mode.
3. Monitored loads will be the sum of the main service panel + essential loads panel.
4. **Energy Priority:** 1. Solar PV Power | 2. Grid Power | 3. Batteries | 4. Generator




Limited Power to Home

Limited Power to Home + Grid Sell

This mode will NOT limit solar production to home demand. In this mode, the inverter delivers power to the **LOAD** terminal (essential loads panel) + excess power to the **GRID** terminal (main service panel AND grid).

The Sol-Ark will monitor grid sell and load consumption simultaneously (with +/- 3% error from CT sensors). The CT sensors **MUST** be installed. The inverter will sell excess solar power up to a programmable limit.

See "2.9 Limit Sensors (CT sensors)" on page 25 for correct placement of external CTs.



Limited Power to Home + Grid Sell


Limited Power to Load

! This work mode **REQUIRES** batteries.

Limited Power to Load limits the solar production to cover **LOAD** demand (essential loads panel) exclusively. In this mode, the system disregards loads in the main service panel and will not deliver power to the **GRID** terminal.

General description


- The inverter will cover only the loads connected to the **LOAD** terminal.
- It will **NOT** produce more power than the load demand.
- This work mode will **NOT** deliver power to the **GRID** terminal (will NOT sell back).
- The loads reported by the inverter will be from only the essential loads panel (**LOAD** terminal).
- This system work mode is recommended for off-grid applications.
- **Energy Priority:** 1. Solar PV Power | 2. Grid Power | 3. Batteries | 4. Generator



Limited Power to Load

Limited to Load + Grid Sell

This mode will NOT limit solar production to **LOAD** demand. The inverter delivers power to the **LOAD** terminal (essential loads panel) + excess power to the **GRID** terminal (main service panel AND grid); however, it will track **LOAD** demand and sell excess solar only up to a programmable limit. **GRID** loads cannot be measured, only the total output through the **GRID** terminal. This mode is recommended for single inverter systems or for whole-home backup installations.




Limited Power to Load + Grid Sell

Time of Use

This mode combined with **Limited Power to Home** or **Limited Power to Load** lets you use battery backup power to reduce consumption from the grid during specific time intervals. Battery power will cover load demand at the programmed **Power (W)** rate until the battery reaches the programmed **Batt (V or % SOC)** limit. You can configure six different time intervals over a 24-hour period to cover a wide range of battery discharge or charge behaviors.

General description

- Uses battery power to reduce the power consumption during user defined time intervals.
- Power (W) dictates the rate at which the battery discharges to assist with load demand.
- Batt (V or %) dictates the lower discharge limit or upper charge limit.
- **Energy Priority:**
 1. Solar PV Power | 2. Batteries (down to programmed discharge V or %) | 3. Grid Power | 4. Generator



Limited Power to Home + TOU

Time: Programmable time intervals over a 24h period. All time slots **MUST** follow chronological order and must be programmed.

Power(W): Sets the maximum discharge rate of the battery during the corresponding time slot.

Batt: V or % used to specify a lower discharge limit or upper charge limit whenever ☒ **Charge** is enabled.

 Grid-tied systems will not allow TOU to discharge lower than **Low Batt V/%**. Off-grid systems allow TOU discharge down to **Shutdown V/%**.

☒ **Charge:** During the hours selected, it's allowed to charge batteries from an external AC source up to a programmed voltage or %. If the external AC power source is a generator, the **Start V** or **Start %** condition must be fulfilled first. If available, the solar array always charges the batteries at 100% regardless of ☒ **Charge** in TOU.

☒ **Sell:** Allows batteries to discharge and sell power to the grid at the programmable "Power(W)" rate.


☒ **Grid Sell MUST** be enabled.

 Do NOT enable **Charge** and **Sell** at the same time.

Specify Times for Peak Shaving


To limit Peak Shaving to certain time periods during the day, follow these steps:

1. Go to:  > **Basic Setup** > **Advanced** tab.
2. Select the **Grid Peak Shaving** check box to enable adjustment of the **Power** field.



The screenshot shows the 'Basic Setup' window with the 'Advanced' tab selected. The 'Grid peak-shaving' checkbox is checked, and the 'Power' field is set to '8000W'. The 'Auto detect Home Limit Sensors' checkbox is unchecked, and the 'CT ratio' is set to '2000'. The 'ARC parameters' section lists several values: 030000, 045000, 000800, 000050, 000530, 045000, 000100, and 238094. The 'CANCEL' and 'OK' buttons are at the bottom.

3. To the right of **Grid peak-shaving**, select the **Power** field and use the up and down arrows to set the usage (in watts) from the grid at which the Sol-Ark will begin Peak Shaving
4. **Uncheck** the **Grid Peak Shaving** check box, then tap **OK**.
5. Tap the **Limiter** button to navigate to the **Limiter** tab on the **System Setup** screen.
6. Select any check boxes under the **Peak** column to specify a time period for grid peak shaving.
7. Select the **Time of Use** check box.
8. Tap **OK** to save the settings and complete programming.




The screenshot shows the 'Limiter Param' window with the 'Other' tab selected. The 'Grid Sell' checkbox is unchecked, and the 'Power' field is set to '15000'. The 'Limited Power to Home' checkbox is unchecked, and the 'Power' field is set to '2000'. The 'Limited Power to Load' checkbox is checked, and the 'Power' field is set to '100%'. The 'Time of Use' checkbox is checked, and the 'Setup' button is highlighted. The 'CANCEL' and 'OK' buttons are at the bottom. The table below shows the 'Peak' column settings for various time periods.

Time	P(W)	Batt	Char.	Sell	Peak
01:00	2000	50%			
05:00	2000	50%			
09:00	2000	100%			
13:00	2000	100%			
17:00	2000	50%			
21:00	2000	50%			

Other

- **GEN Connect to Grid Input:** Specifies when a generator is connected to the **GRID** terminal.
- **Zero Export Power:** Minimum power imported from the grid. Helps avoid selling back by ensuring constant grid consumption. The value can be set between 1 - 100W (**recommended 20W**).
- **Batt First:**  Default and recommended option. Sets the solar power priority of the system to charge batteries first. Do NOT change unless instructed by Sol-Ark technical support.
- **Load First:** Sets the solar power priority of the system to cover loads demand first and deliver remaining power to batteries.
This is recommended only for very specific situations.

3.6 Grid Setup



The Grid Setup process consists of five sequential screens:

- Grid Param (Screen 1):** Selects Grid Mode (UL1741SB), Grid Frequency (50Hz/60Hz), Single Phase, 120/240V Split Phase, and 120/208V 3 Phase. It also sets Grid Reconnect Time (300s), Power Factor (1.000), Fixed Q (0%), Q_Response (10s), Output V (120/208V), and Output V+ (+0V).
- Grid Param (Screen 2):** Configures Reconnect and Normal connect settings for Grid Vol High/Low and Grid Hz High/Low, along with Reconnect and Normal Ramp rates (60s).
- Grid Param (Screen 3):** Sets Over Voltage U>(10 min. running mean) to 239.2V. It configures HV3, HV2, HV1, LV1, LV2, and LV3 voltage levels and their corresponding time delays.
- Grid Param (Screen 4):** Configures Over frequency and Under frequency settings, including Start/Stop frequencies and delays, and Droop F/F+ (40%PE/Hz).
- Grid Param (Screen 5):** Configures V(W) and V(Q) response times and limits, and P(Q) and P(F) response times and limits.

Grid Selection

Grid Mode: Tap and use navigation arrows to cycle through different grid modes:

- **General Standard:** Applies general grid interconnection standards. Enables grid frequency and voltage adjustments. (Useful for off-grid applications with backup generators).
- **UL1741 & IEEE1547:** Applies UL 1741 and IEEE 1547 grid interconnection requirements and standards.
- **UL1741SB:** Applies UL 1741SB grid interconnection requirements and standards.

Grid Frequency: Frequency of the AC sine wave.

Grid Type: Determines the type of system voltage and grid interconnection. Includes Single-Phase, Split-Phase, and 3-Phase.

Grid Reconnect Time: The amount of time in seconds the inverter will wait before reconnecting to the grid.

Power Factor: Allows for power factor correction, ± 0.9 to 1.0.

Fixed Q: Allows for power factor correction based on desired reactive power percentage.

Q_Response: Time required for the inverter to respond to supported Volt-Var or Watt-Var functions.

Output V: Tap and use navigation arrows to cycle through different nominal grid voltage levels. Grid level must be selected according to nominal grid voltage.

Output V+: Allows fine voltage modifications to the Output V to ensure proper nominal voltage.

Connect

Reconnect: These parameters determine an allowable range of frequency and voltages for a reconnection to the grid after initial grid loss. Frequency and voltages must be within these margins during Grid Reconnect Time to allow reconnection to the grid.

! Parameters are set automatically based on selected grid mode compliance unless you select **General Standard**.

Normal connect: These parameters determine the allowable range of frequency and voltages to stay connected to the grid after a reconnect and normal operation.

! Parameters are set automatically based on selected grid mode compliance unless you select **General Standard**.

Reconnect Ramp Rate: Reconnection power ramp time in seconds.

Normal Ramp Rate: Startup power ramp time in seconds.

IP

HV1/HV2/HV3: Overvoltage protection point.

LV1/LV2/LV3: Undervoltage protection point.

HF1/HF2/HF3: Over frequency protection point.

LF1/LF2/LF3: Under frequency protection point.

F(W)

F(W): Enables using Frequency-Watt. The Sol-Ark regulates its power output to the grid as a function of the frequency to support grid stabilization during periods of over- and under-frequency.

Droop F: Percentage of inverter's nominal power increase or decrease per Hertz (Hz).

Start freq F: Frequency at which the inverter will start decreasing active power by the programmed Droop F percentage.

Stop freq F: Frequency at which the inverter will stop decreasing active power by the programmed Droop F percentage.

V(W) / V(Q)

V(W): Enables using Volt-Watt. The Sol-Ark regulates active power output to the grid as a function of voltage to help with stabilization during over- and under-voltage conditions.

V(Q): Enables the use of Volt-VAr. The Sol-Ark regulates reactive power output to the grid as a function of the voltage to support stabilization during periods of over and under-voltage.

V, P & Q: Percentage of nominal grid voltage (V) to which the Sol-Ark will reduce its active power (P) or reactive power (Q).

P(Q) / P(F)

P(Q): Enables using Watt-VAr to regulate reactive power output according to programmable active power parameters.

P(F): Enables PF regulation according to programmable active power parameters.

! Follow electrical grid code before changing grid settings

4. Installation Tips

4.1 Off-Grid Installation Tips

1. Limit sensors (CTs) are not required for completely off-grid installations UNLESS using Grid Peak Shaving for a generator connected to the **GRID** terminal or installing a parallel inverter system.
2. Connecting generators to the **GRID** terminal is recommended to facilitate integrating a **GEN**-connected service panel. This setup enables use of the **Smart Load** function.
3. There is no need for a transfer switch. Connect the **LOAD** output to the main panel.
4. **DO NOT** use **Grid Sell** mode when Off-Grid. ONLY **Limited Power to Load** (default work mode) in single inverter systems and **Limited Power to Home** in systems with multiple inverters.
5. When using a Generator in an Off-Grid situation, it's recommended to change the **Grid Mode** to **General Standard** and the **Grid Reconnect Time** to **30 seconds**. See section "2.5 Integrating a Generator" on page 16 for instructions.
6. The **Auto Gen-Start** activates when the battery voltage (V) or percentage (%) reaches the pre-set **Start V / %** value. Subsequently, the generator will sustain the charging process until the batteries reach approximately 95% capacity.
 - ! This is a non-modifiable upper limit unless Time of Use is enabled and programmed.
 - An exercise function will turn on the generator once a week on Monday mornings at 8:00 a.m. for 20 minutes by default. This exercise is done to maintain the internal generator batteries.
7. If you plan to integrate a wind turbine, you MUST incorporate a 48 V charge controller with a dump load to prevent battery overcharge. This charge controller must be connected directly to the battery bank.
8. Remember to set the battery capacity and reasonable charge/discharge rates.

4.2 Grid-Tie and No Battery Install Tips (Passthrough mode)


1. Check the ☒ **No Battery** setting: ⚙️ > **Battery Setup** > **Batt** > **No Battery**. The inverter will fault momentarily.
 - ! A complete **Power Cycle IS REQUIRED** when changing the battery mode to **No Battery**. See "2.12 Power Cycle Sequence" on page 32 for instructions.
2. Enable ☒ **Grid Sell**: ⚙️ > **Limiters** > **Grid Sell**. *Be sure to disable all other modes.*
DO NOT check the **Parallel** check box in systems with multiple inverters and no battery bank.
Settings: > **Basic Setup** > **Parallel Tab** > **Parallel**
3. Tap the battery Icon to access the **Details** screen and verify grid parameters and power import/export.

4.3 Battery Charge Controller

4-Stage Charging

The MPPT has a 4-stage battery charging algorithm for rapid, efficient, and safe battery charging. The next figure shows the stage sequence.

Note: If you are not using closed-loop communications, the inverter will follow the stages below.



Bulk Charge Stage (CC)

In the Bulk Charge stage, the battery is not at a 100% state of charge and has not yet reached the Absorption voltage setpoint. The controller will deliver 100% of available solar power to recharge the battery.

Absorption Stage (CV)

When the battery has reached the absorption voltage setpoint, the Sol-Ark inverter uses constant-voltage regulation to maintain battery voltage at the absorption setpoint, preventing overheating and excessive battery gassing. The battery is allowed to come to a full state of charge at the absorption voltage setpoint. Absorption lasts until the battery charge amperage (A) rate reaches 2% of the programmed capacity (Ah).

Float Stage (Resting)


After the Absorption stage charges the battery fully, the MPPT reduces the battery voltage to the float voltage setpoint. If the batteries have 100% charge, there can be no more chemical reactions, and all the charging current turns into heat and gassing. The Float stage provides a minimum rate of maintenance charging while reducing the heating and gassing of a fully charged battery. The purpose of the Float stage is to protect the battery from long-term overcharge.

4.4 Local Grid Compliance Settings

See [Local Grid Compliance Settings](#) for required settings for Hawaii and Puerto Rico.

5. Parallel Systems

5.1 Before Enabling Parallel Operations



- A. Make sure all units in parallel have the same software version by verifying the **COMM** and **MCU** numbers on the **System Setup** screen.
- B. Go to <https://www.sol-ark.com/software-update/> to schedule an update or contact Sol-Ark Technical Support for help at: support@sol-ark.com

Parallel systems **REQUIRE** a joint battery bank. If you do not have a battery, keep all Sol-Ark inverters **OUT** of parallel and set every System to **Grid Sell** Mode.


For systems with no battery, do NOT check the **Parallel** box on operation:

 > **Basic Setup** > **Parallel** > ☒ **Parallel**.

- C. All INPUTS/OUTPUTS must be shared among **ALL** parallel inverters, except for DC solar inputs.

DIP Switch Configuration for Parallel Systems

In parallel systems, set the "DIP Switches" as shown, according to the table below.



Inv 1 (Master)	Inv 2	Inv 3	Inv 4	Inv 5	Inv 6	Inv 7	Inv 8	Inv 9	Inv 10	Inv 11	Inv 12
OFF											
! ON	! ON										
OFF	ON	OFF									
OFF	ON	ON	OFF								
OFF	ON	ON	ON	OFF							
OFF	ON	ON	ON	ON	OFF						
OFF	ON	ON	ON	ON	ON	OFF					
OFF	ON	ON	ON	ON	ON	ON	OFF				
OFF	ON	ON	ON	ON	ON	ON	ON	OFF			
OFF	ON	ON	ON	ON	ON	ON	ON	ON	OFF		
OFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF	
OFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF

! Parallel systems with 2 inverters must have their DIP switches in the ON position

Parallel Systems Sol-Ark 15K-2P-LV @ 120/240 V Split-Phase

# of inverters in parallel	Continuous output power with PV (kW)	Continuous output power with batteries (kW)	Max. Grid Passthrough Current (A)	Peak power 10 sec (kVA)
1*	15	12	200	24
2	30	24	400	48
3	45	36	600	72
4	60	48	800	96
5	75	60	1000	120
6	90	72	1200	144
7	105	84	1400	168
8	120	96	1600	192
9	135	108	1800	216
10	150	120	2000	240
11	165	132	2200	264
12	180	144	2400	288



Parallel Systems Sol-Ark 15K-2P-LV @ 120/208 V 3-Phase

# of inverters in parallel	Continuous output power (kW)	Continuous output power with batteries (kW)	Grid Passthrough (A)	Peak power 10 sec (kVA)
1 (only 2 phases) *	13	10.4	200	20.8
2 (all phases but unbalanced)	26	20.8	400	41.6
3	39	31.2	600	62.4
6	78	62.4	1200	124.8
9	117	93.6	1800	187.2
12	156	124.8	2400	249.6


* For single-inverter systems, enabling the **Parallel** option on the **Parallel** tab is not required. Select the appropriate grid type and voltage for your application (such as split-phase, three-phase, etc.).

5.2 Parallel Systems Programming Sequence

1. Program each inverter for parallel operation: ⚙️ > **Basic Setup** > **Parallel** > ☒ **Parallel**
2. Assign the "Slave" unit as | **Modbus SN: 2, 3, 4...**etc.
3. Assign a "Master" inverter, **Modbus SN: 1**. If a system is 3-Phase, there **MUST** be a "Master" for each phase (**Master Phase A, Master Phase B, Master Phase C**)
4. Connect communication cables between the inverters using the RJ-45 cable (yellow Ethernet cable) in daisy-chain configuration between ports: Parallel_1 or Parallel_2 from "Master" to "Slave" or "Slave" to "Slave."
5. Perform a power cycle (see "2.12 Power Cycle Sequence" on page 32).
6. After the power cycle is completed, turn on the "Slave" units **FIRST**. Then turn ON the "Master" **LAST**.
Inverters will likely fault momentarily with F29 and F41 codes until all inverters are ON.




When integrating a generator, it must be connected to all the systems in parallel. The inverter assigned as "Master" will control the two-wire start feature.



Parallel setup tab


Parallel Configuration (Example on a 3 Phase System-Balanced). Phase A-B-C

A 3-Phase balanced system requires at least 3 Sol-Ark Units. Follow the illustrations below for programming and wiring.




Examples of 3-Phase Parallel Configurations

2 inverters @ 120/208 V using **2 phases of 3**



2 inverters @ 120/208 V using **3 phases of 3 (Unbalanced)**




5.3 Three-Phase Systems

Three-phase systems with multiple Sol-Ark inverters must be programmed according to this table:

Number of inverters	Programming
2	Master Phase A 01 Master Phase B 02
3	Master Phase A 01 Master Phase B 02 Master Phase C 03
6	Master ΦA 01, Slave ΦA 02 Master ΦB 03, Slave B 04 Master ΦC 05, Slave ΦC 06
9	Master ΦA 01, Slave ΦA 02, Slave ΦA 03 Master ΦB 04, Slave ΦB 05, Slave ΦB 06 Master ΦC 07, Slave ΦC 08, Slave ΦC 09
12	M ΦA 01, S ΦA 02, S ΦA 03, S ΦA 04 M ΦB 05, S ΦB 06, S ΦB 07, S ΦB 08 M ΦC 09, S ΦC 10, S ΦC 11, S ΦC 12

Troubleshooting Guide with Phase Sequence

! If the screen of the Sol-Ark inverter shows the error shown below, ensure the phase sequence follows **AB-BC-CA** convention. The message "Grid Phase Wrong" is displayed when the inverter does not detect the correct phase sequence. This situation can cause overloads faults in the system (F18, F26, F34) even with the **LOAD** disconnected and **WILL CAUSE DAMAGE** to the equipment if it is not corrected.



	L1	L2
Inverter (1)	A	B
Inverter (2)	B	C
Inverter (3)	C	A

How to find an incorrect phase if you see the message “Grid Phase Wrong”


1. Measure L1 GRID of inverter (1) to L2 GRID of inverter (3). Should be 0 VAC.
2. Measure L2 GRID of inverter (1) to L1 GRID of inverter (2). Should be 0 VAC.
3. Measure L2 GRID of inverter (2) to L1 GRID of inverter (3). Should be 0 VAC.
4. Do the same process for the LOAD side.

Measuring voltage different than 0 VAC means the measured lines are not the same phase.

Sol-Ark can receive only direct rotation “C” (clockwise).

Be sure to check both **GRID** and **LOAD** terminal connections; both must be correct. If the error persists, check your AC connection beyond the inverter and verify that the phases are correctly labeled from your meter.

***In 3-phase systems, it’s recommended to use a rotational tester (1-2-3, A-B-C).**



If an inverter goes into a fault state, all other units will stop and follow. The system will automatically self-reboot.
If the system faults 5 consecutive times, it will stop completely and it will require a manual restart. See “2.12 Power Cycle Sequence” on page 32.

6. MySolArk: Remote Monitoring




MySolArk is a powerful and comprehensive tool designed for remote system monitoring of Sol-Ark inverters and solar systems. This remote monitoring solution offers detailed insights into energy generation and power consumption, allowing users to track system performance with great precision. MySolArk displays all relevant electrical data on easy-to-understand energy generation graphs, providing a comprehensive overview of electrical usage.

Beyond its monitoring capabilities, **MySolArk** offers users the flexibility to remotely adjust inverter settings, allowing them to seamlessly configure their system from any location. This ensures that users can fine-tune parameters to optimize performance effortlessly. With **MySolArk**, users can confidently manage their solar systems and inverters to ensure peak performance and efficiency at all times. Visit www.mysolark.com to access the desktop version of MySolArk.

6.1 Setting Up MySolArk


Connect to MySolArk through Ethernet

- Remove the plastic enclosure of the dongle by pressing the plastic latches with a flat screwdriver as shown in the figure below.
- Insert the Ethernet cable through the plastic enclosure and connect the cable to the RJ45 port.
- Reassemble the dongle housing and plug the dongle into the Sol-Ark, securing it with screws. You'll see solid red and green lights after a couple of minutes.
- Follow the Step 1 instructions below to create a plant on MySolArk.



Connect to MySolArk through Wi-Fi

- Plug the Wi-Fi dongle into the Sol-Ark DB-9 port.
- Use two M4X10 screws to secure the dongle to the port.
- Follow Steps 1-3 in order to:
 - Create a plant on the MySolArk monitoring platform.
 - Connect the dongle to MySolArk through a Wi-Fi network.



Step 1: Create a "Plant" on MySolArk

A. **Download and install the MySolArk_app** for Android or Apple smartphones. You can use the QR codes below.



Google Play Store




MySolArk



Apple App Store

B. Create a **MySolArk** account and log in.




C. Create the plant.

For Installers:




Create the plant and configure the system before sharing it with the owner.

After creating and configuring the plant, share and grant manager permissions to the owner by navigating to **My Plants > ... > Share > Add Account**. The homeowner must create their own **MySolArk** account first.



Step 2: Configure Wi-Fi network through MySolArk

D. Configure Wi-Fi network.




Note: You can access the Wi-Fi configuration tool at any other time by tapping **Me** at the bottom right corner, then **Tools > Wi-Fi configuration**. Step 3 shows another method of connecting the Wi-Fi dongle to a local network through an IP address.

Step 3 (alternate method): Configure Wi-Fi Network using an IP Address

As an alternative to the "Distribution Network" configuration at the end of Step C, or using the "Wi-Fi configuration" tool, you can configure a Wi-Fi network through an IP address.

- On a smartphone or computer, connect to the EAP-##### network.
Go to: **Settings > Wi-Fi > EAP-##### network**.
- Type in the password, which depends on the product you received:
 - If you see "KEY" printed on the dongle, the 16-digit password is printed there
 - If there is no "KEY" printed on the dongle, the password is 12345678

The EAP-##### network contains the last five digits of the Dongle serial number. You can find this number on the label.
- A message such as "Connected without internet" appears when the device is connected to the EAP-#####.



Locating the Dongle Network Name




Note: The Wi-Fi dongle does NOT provide internet access. It needs an external internet provider to connect to.
The dongle is compatible with the Wi-Fi signal broadcast at 2.4 GHz (it's not possible to use 5 GHz).

- After you're connected, open an internet browser on that same device such as Safari, Chrome, Firefox, Edge, or any other browser.
- On the address bar (**http://.....**), type the IP address: **10.10.10.1** as shown in the figure below. If you cannot access the configuration page, try again on a different device.
- Scroll down to the **WLAN Connection** section and tap the **Scan** button to scan for local Wi-Fi networks.
- Nearby Wi-Fi networks will appear. Select the local network you would like to connect to, input your credentials, and tap **Connect**.
- Once connected, a "Connection Successful" message appears. Tap the **Save** button next to **Scan** to save settings.
- Wait a few minutes. The dongle will connect to the Wi-Fi network, and you'll now have access to **MySolArk**.



Note: DO NOT connect to the EAP-##### network, as that is the Wi-Fi dongle itself. The device does not provide internet access.




a. Internet Browser IP Address



b. Wi-Fi Network Scan

If the connection is successful, you'll see the following LED indicators.

- **SOLID:** Connected and powered by the Sol-Ark inverter.
- **SOLID:** Connected to the router and to MySolArk.
- **INTERMITTENT:** Connected to the router but not to the server (usually a VPN or Firewall problem). Ports 80 and 51100 must be enabled.



Wi-Fi Dongle LED Indicators



Connecting through the 10.10.10.1 IP address is only meant to provide internet access to the Wi-Fi dongle. Users must still create a MySolArk account and must create a plant. Go to www.mysolark.com to access the desktop version of MySolArk.

6.2 LED Indicator and Troubleshooting

When both the red and green LEDs on the Wi-Fi dongle are consistently illuminated, it signifies normal operation, while flashing indicates data transmission. If this isn't the case, reference the next table of LED indications for troubleshooting and corrective measures.

 **RED LED:** Device communication indicator.

 **GREEN LED:** MySolArk server communication indicator.

LED	State	Meaning
	Initial flashing, then constant illumination	Normal communication.
	Initial flashing but no further illumination	Communication failure. Check proper device connection.
	LED not illuminating	Power supply or device is abnormal. Contact Sol-Ark Technical Support.
	5-second illumination interval	Normal communication.
	1 flash every minute	Router not connected.
	3 flashes every minute	Connected to router but no internet access. Usually, this indicates a VPN or firewall issue. Ports 80 and 51100 must be enabled.
	4 flashes every minute	Device communication error. Contact support.
	2 synchronized flashes	Ethernet cable inserted
	3 synchronized flashes	Ethernet cable disconnected

7. Wiring Diagrams

CAUTION: The following diagrams are general use cases. Please remember that it's mandatory to adhere to local electrical codes and regulations.



While these diagrams offer general guidance, they may not encompass all variations and specifics required by local codes. Consult with relevant authorities and ensure compliance before proceeding with any installation.


The diagrams in the following pages are not exhaustive and should not be relied upon solely for permitting or warranty verification. Please use caution, seek professional advice when necessary, and undertake installations with due diligence and in accordance with established electrical standards and regulations.




WARNING:

Use only designated cable entry points. Drilling or altering the chassis without Sol-Ark written authorization will void any warranty and may adversely affect performance and safety.


7.1 Sol-Ark 15K-2P-LV Standard Wiring Diagram




7.2 Sol-Ark 15K-2P-LV Standard Wiring Diagram – Line Side Tap




7.3 Sol-Ark 15K-2P-LV Standard Wiring Diagram - AC Coupling in GEN




7.4 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Whole-Home Generator




7.5 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Off Grid




7.6 Sol-Ark 15K-2P-LV Standard Wiring Diagram - Bypass Transfer Switch



7.7 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 2 Parallel Inverters | 120/240V




7.8 Sol-Ark 15K-2P-LV Standard Wiring Diagram – 3 Parallel Inverters | 120/240V




Before powering up Parallel System installs, see section 5 "Parallel Systems"

7.9 Sol-Ark 15K-2P-LV Standard Wiring Diagram – 2 Parallel Inverters | 120/208V



7.10 Sol-Ark 15K-2P-LV Standard Wiring Diagram - 3 Parallel Inverters | 120/208V



Before powering up Parallel System installs, see section 5 "Parallel Systems"

8. Troubleshooting Guide

LCD is not powering on

- Check all connections - at least one of the following power sources is required: PV/Grid/Battery
- Try pressing the power button, touchscreen, or navigation buttons

Panels are connected, but "DC" LED indicator is not on

- Minimum starting voltage is 125 V. Voltage must be above 125 V and below 500 V
- Wrong polarity. Check string polarity on MPPT
- PV DC disconnect is not in the ON position

Panels are not producing

- Check for proper wiring on all solar panel connections
- Turn PV disconnect "ON"
- Check that the PV input voltage is not greater than 500 V
- If the system measures 0 V even when PV DC disconnect is ON, polarity might be wrong. Check PV polarity

Panels are not producing much power

- PV Wire Strip Length: 5/8". Your batteries are charged and are limited to house loads; you can test Grid Sell to verify.

The system does not keep batteries charged

- Verify there is proper communication between the Sol-Ark and the battery: ⚙️ > **Li-Batt Info**
- Verify proper Charge and Voltage settings according to battery manufacturer and battery bank arrangement

Auto Gen-Start is not working

- Make sure the generator has a compatible two-wire start interface
- Verify adequate connection to the Sol-Ark auto-start input pins

"Normal" LED indicator is not on

- Sol-Ark is in pass-through-only mode, only a Grid connection
- Not fully energized (DC Solar panels AND Grid or just batteries)
- In alarm state
- Sol-Ark is not working correctly. Call Sol-Ark Technical Support at +1 (972) 575-8875 ext. 2

The "Alarm" LED indicator is on

- Check the system alarms menu to identify the alarm

Grid HM value is negative when it should be positive (only applies in Limited to Home mode)

- Limiter Sensors are backwards, L1/L2 sensors are swapped, or incorrectly wired.

Execute the **Auto Learn Home Limit Sensors** command described in "2.9 Limit Sensors (CT sensors)" on page 25.

AC Overload Fault or Bus Unbalance Fault

- Check Transfer Switch/Subpanel wiring
- Check for large loads that consume more than the inverter rating

The system connects to grid and quickly disconnects

- Verify Neutral wire connection (0 VAC referenced to GND)
- Check the programmed frequency, and verify the Sol-Ark measures 120 V between L and N
- If the system is overloading, verify the proper phase sequence between **GRID** and **LOAD** terminals

DC Overload Fault

- Check PV voltage. Ensure no more than 500 V
- Make sure you have not wired more than 2 solar strings in parallel per MPPT

System is beeping

- Check the System Alarms menu to see which alarm has been triggered. Most alarms will self-reset
- Do a Power Cycle as shown in "2.12 Power Cycle Sequence" on page 32.

Battery cable sparks when connected

- If applicable, flip the built-in breakers of the battery bank before connecting or disconnecting batteries

Battery symbol on the home screen is red

- The battery is below the empty voltage
- Battery is over-voltage

Battery symbol on the home screen is yellow

- The battery is low, or the charge/discharge current is close to the programmed limit

Grid symbol on the home screen is yellow

- Grid parameters are out of specified operating range
- There is a grid outage and there is no voltage on the **GRID** terminal
- System is Off-Grid

System has restarted

- Occurs when the system has overloaded or when the battery voltage has exceeded 59 V
- There was a software update

Batteries were connected backwards

- ⚠ The system may be damaged and the warranty may be voided.

Why is the LCD screen still on when the power button is off?

- This happens when the power button is in the "OFF" position
- This happens when the system is not fully energized: PV or Grid only

The Batt SOC% is not reaching 100%

- The Sol-Ark might be in the calibration phase and estimating the battery SOC. We suggest waiting three full days to let the unit go through the 4-stage charging curve to converge to an accurate percentage.
- If the suggestion above does not work, you can re-adjust the battery capacity under **Battery Setup > Batt Capacity** to restart the calibration process

Generator setup is reading 0 Hz

- Generator is operating at a frequency outside the permissible range. Select **General Standard** grid mode. Widen the frequency range to 55 Hz-65 Hz as described in "2.5 Integrating a Generator" on page 16.

Color Touchscreen is Frozen

- Press and hold the Escape button (◀) for 7-10 seconds.
- If the Escape button doesn't work, do a power cycle sequence as shown in "2.12 Power Cycle Sequence" on page 32.

Grid Phase Wrong

- ⚠ If the Sol-Ark screen shows a "Grid Phase Wrong" message, it means there is a phasing issue in the wiring. If left unchecked, it may cause overload faults and **DAMAGE**. See "5.3 Three-Phase Systems" on page 57.

8.1 Sol-Ark Error Codes

Fault	Instruction	Common Cause/Remedy
F1	DC_Inversed_Failure	If you have parallel systems and turn one system off, you will get this notification. NOT a fault.
F8	GFDI_Relay_Failure	Check for continuity on the inverter's neutral and ground. Ensure there is only ONE neutral-to-ground bond in the system. Current Leakage from inverter AC output to Ground, check Ground and neutral are connected at the main panel.
F13	Grid_Mode_change	This happens when not using batteries or if Grid Input settings are changed. This is a notification, NOT a fault. If you switch from No Batt to Battery mode, power down completely to restart.
F15	AC_OverCurr_Failure	It is usually caused by Loads too large for the inverter. If Off-Grid, the battery discharge Amps are programmed too low. Overloads can result in F15, F18, F20, or F26.
F16	GFCI_Failure	Ground fault. Check PV+ or PV- wiring (which must be ungrounded). Exposed PV conductors + rain can also cause. Check that the neutral line and Ground are not double-bonded (common with portable generators).
F18	Tz_AC_OverCurr_Fault	Overloaded the Load Output (reduce loads) or overloaded a generator (reduce Gen Start A). Wiring Short on AC Side can also cause this error. Overloads can result in F15, F18, F20, or F26.
F20	Tz_Dc_OverCurr_Fault	It is typically caused by DC current from the battery that is too large (ex: 4 Ton AC Unit) or too much PV current (3 or more strings in parallel). Overloads can result in F15, F18, F20, or F26.
F22	Tz_EmergStop_Fault	Initiated Emergency Stop; see sensor pinout table.
F24	DC_Insulation_Fault	An exposed PV conductor combined with moisture is faulting (can cause F16, F24, and F26).
F25	DC_Feedback_Fault	No battery connection to the Inverter and Activate Battery is enabled. Disable Activate Battery in settings while no battery is connected.
F26	BusUnbalance_Fault	Too much load on one leg (L1 or L2) vs. the other leg or DC loads on the AC output when Off-Grid. Grounded PV+/- wire can cause F20, F23, or F26.
F29	Parallel_Canbus_Fault	Usually, a communication error for parallel systems. Check cables, and Modbus addresses.
F30	AC_MainContactor_Fault	Possibly caused by fused grid relay. Disconnect grid from inverter. If Normal light stays on, the grid relay is likely fused. Otherwise, contact Sol-Ark Technical Support.
F31	Soft_Start_Failed	Soft Start of the large motor failed.
F34	AC_Overload_Fault	AC Overload or load shorted. Reduce heavy loads.
F35	AC_NoUtility_Fault	Grid connection lost.
F37	DCLLC_Soft_Over_Cur	Software DC overcurrent.
F39	DCLLC_Over_Current	Hardware DC overcurrent.
F40	Batt_Over_Current	Batteries exceeded their current discharge limit.
F41	Parallel_System_Stop_Fault	If one system faults in parallel, this normal fault will register on the other units as they disconnect from the grid.
F45	AC_UV_OverVolt_Fault	Grid under voltage causes a disconnect. This will self-reset when the grid stabilizes.
F46	Battery_Backup_Fault	Cannot communicate with other parallel systems. Verify that the Master is set to 1, the Slaves are set to 2–9, and the Ethernet cables are connected.
F47	AC_OverFreq_Fault	Grid over Frequency (common in power outages) causes disconnect. Will self-reset when grid stabilizes.
F48	AC_UnderFreq_Fault	Grid under Frequency (common in power outages) causes a disconnect. Will self-reset when grid stabilizes.
F55	DC_VoltHigh_Fault	PV may be higher than 500 V. Battery voltage should not be above 59 V.
F56	DC_VoltLow_Fault	Batteries are overly discharged, the inverter is Off-Grid and exceeded the programmed batt discharge current by 20%, or Lithium BMS has shut down. If battery settings are incorrect, this can also happen.
F58	BMS_Communication Fault	Sol-Ark is programmed to BMS Lithium Battery Mode but cannot communicate with a BMS. BMS_Err_Stop is enabled, but cannot communicate with a battery BMS.
F60	Gen_Volt_or_Fre_Fault	Generator Voltage or Frequency went outside the allowable range.
F61	Button_Manual_OFF	The parallel Slave system turned off without turning off the Master.
F63	Arc_Fault	Can be a poor PV connector/connection, or a false alarm due to powerful lightning storms.
F64	Heatsink_HighTemp_Fault	See if built-in fans are running; the ambient temperature may be too high. Ensure proper clearance.

9. Installation Checklist

AFTER the system is operational, please register your product by filling out this verification checklist and sending it to Sol-Ark. Go to <https://www.sol-ark.com/register-your-sol-ark/> to register.



Installer/Company: _____ Date: (YYYY-MM-DD) _____

Inverter SN: _____ Gateway SN: _____

Mark ☒ for all that apply

Indicate the type of system (all that apply):

☐ Grid-Tied only ☐ Grid-Tied with battery backup ☐ Off-Grid ☐ Parallel system: # _____ inverters

Indicate integrated components (all that apply):

☐ Utility grid	☐ DC solar panels	☐ AC-coupled solar panels	☐ Generator
☐ LOAD installed service panel	☐ GRID installed service panel	☐ GEN installed service panel	☐ Lithium batteries
☐ Lead-Acid batteries	☐ Wind Turbine		

⚠ It is strongly recommended to send a **Wiring Diagram** of the installation to support@sol-ark.com for verification, otherwise Sol-Ark expressly disclaims any responsibility for performance issues arising from improper installation. Installers and users are solely responsible for following proper installation procedures outlined in provided documentation. Sol-Ark disclaims any liability for changes in the installation that might result in electrical malfunctions or any other issues related to the Sol-Ark product.

! Circle **N/A** (Not Applicable) if the verification step is not relevant to the type of system or does not apply to the integrated components.

A wiring diagram of the installation was sent to Sol-Ark for verification	☐ Y ☐ N
Setup for remote system monitoring through Wi-Fi / Ethernet is completed... Gateway SN: _____	☐ Y ☐ N
The inverter is installed in a location where the LCD screen is always protected from direct sunlight	☐
The inverter has the minimum specified vertical and lateral clearance for proper heat dissipation	☐
The maximum DC input voltage does not surpass 500 V _{DC}	☐
The battery bank does not surpass 59 V _{DC}	☐
All battery conductors are properly connected and secured to the (+, -) terminals of the inverter	☐ N/A
Battery communication was successfully established	☐ N/A
All Battery Setup parameters are programmed according to battery manufacturer specifications	☐ N/A
The Sol-Ark generates power from the PV array and charges the battery bank correctly	☐ N/A
Grid / Generator is properly connected to the Sol-Ark and the phase sequence was verified	☐ N/A
☒ Grid / Gen Charge settings are programmed correctly. Grid / Generator adequately charge the batteries	☐ N/A
For Off-Grid systems: The mode General Standard is programmed and the V & f ranges are increased	☐ N/A
When ☒ Grid Sell is enabled, the Sol-Ark sells power back to the grid (negative HM measurements for L1, L2)	☐ N/A
Limit sensors are correctly installed on Grid lines / Generator lines	☐ N/A
Only when ☒ Limited Power to Home is enabled, the Sol-Ark matches total load demand (Meter Zero)	☐ N/A
Disconnect the grid: during Off-Grid operation, the inverter properly supplies LOAD demand for PV and batteries	☐ N/A
Disconnect the grid AND solar panels: during Off-Grid operation, the inverter properly draws power from batteries	☐ N/A


Installer name and signature

Customer name and signature

Date

10. GUI Screens

10.1 Main Menu



Solar	Grid	INV	USP LD	Batt
0W	0W 0.0Hz	0W 0.0Hz	0W 0V	0W
M1: 0V 0.0A 0W	0V HM: 0W LD: 0W	0V 0.0A 0W	0W 0V 0W	0V 0.0A 0.0C
M2: 0V 0.0A 0W	0V HM: 0W LD: 0W	0V 0.0A 0W	Gen 0V 0.0Hz 0W	TEMP DC: 0.0C AC: 0.0C
M3: 0V 0.0A 0W				

System Setup 08/14/2025 03:05:27 PM Thurs.

Basic Setup

System Alarms

Battery Setup

Li-Batt Info

Limiter

Grid Setup

- ID: #####
- COMM: ####
- MCU: Ver####

System Alarms 1/25/2021 03:05:27 PM Mon.

Alarms Code	Occurred
F13 Grid_Mode_changed	2021-01-13 11:22
F13 Grid_Mode_changed	2021-01-13 11:20

0.00 V	0.00 A	0.0 C	0%	0 Ah
0.0 V	0.0 V	0A	0A	0x00 0x00
Only w/ BMS Lithium Mode				
1. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
2. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
3. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
4. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
5. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
6. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
7. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
8. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
9. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
10. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
11. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
12. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0
13. 0.00 V	0.00 A	0.0 C	0.0%	0.0V 0.0A 0j0j0

10.4 Limiter

Grid Param
Limiter Other

☐ Grid Sell 15000

☐ Limited Power to Home

☒ Limited Power to Load

☐ Time of Use Setup

Time	Power(W)	Batt	Charge	Sell
01:00AM	2000	50%		
05:00AM	2000	50%		
09:00AM	2000	100%		
01:00PM	2000	100%		
05:00PM	2000	50%		
09:00PM	2000	50%		

Time of Use Setup

☒ Mon. ☒ Tues. ☒ Wed. ☒ Thur.
☒ Fri. ☒ Sat. ☒ Sun.
☒ Season1 ☒ Season2 ☒ Season3

CANCEL

OK

Grid Param
Limiter Other

☒ GEN connect to Grid Input

Zero Export Power 10W

☒ Batt First ☐ Load First

CANCEL

OK

10.5 Grid Setup

Grid Param
Grid Selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

Grid Mode 3/3
UL1741SB
Grid Frequency
☐ 50Hz ☒ 60Hz
☐ Single Phase
☐ 120/240V Split Phase
☒ 120/208V 3 Phase

Grid Reconnect Time 300s
Power Factor 1.000
Fixed Q 0%
Q_Response 10S
Output V 120/208V
Output V+ +0V

CANCEL

OK

Grid Param
Grid Selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

Reconnect
Grid Vol High 228.6V
Grid Vol Low 183.2V
Grid Hz High 61.5Hz
Grid Hz Low 58.5Hz
Reconnect Ramp rate 60s

Normal connect
Grid Vol High 249.6V
Grid Vol Low 104.0V
Grid Hz High 62.0Hz
Grid Hz Low 57.0Hz
Normal Ramp rate 60s

CANCEL

OK

Grid Param
Grid selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

Over Voltage U>(10 min. running mean) 239.2V

	V(W)	V(Q)	F(W)	F(Q)
HV3	249.6		62.00Hz	
HV2	249.6V	0.16s	62.00Hz	0.16s
HV1	249.6V	13.00s	61.50Hz	299.00s
LV1	183.0V	21.00s	58.50Hz	299.00s
LV2	145.6V	2.00s	57.00Hz	0.16s
LV3	104.0V		57.00Hz	

CANCEL

OK

Grid Param
Grid selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

Over frequency
Start freq F 60.50Hz
Start delay 0.00s

Droop F 40%PE/Hz
Stop freq F 60.50Hz
Stop delay 0.00s

☒ F(W)

Under frequency
Start freq F> 59.50Hz
Start delay F> 0.00s

Droop F> 40%PE/Hz
Stop freq F> 59.50Hz
Stop delay F> 0.00s

CANCEL

OK

Grid Param
Grid selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

☐ V(W) ☐ V(Q)

Response_T P1:100%
V1:109.0% P1:100%
V2:110.0% P2:50%
V3:111.0% P3:0%
V4:112.0% P4:0%

Lin:20.0% Lout:5.0%
V1:90.0% Q1:43%
V2:94.0% Q2:0%
V3:106.0% Q3:0%
V4:110.0% Q4:-43%

CANCEL

OK

Grid Param
Grid selection Connect IP F(W) V(W)/V(Q) P(Q)/P(F)

☐ P(Q) ☐ P(F)

P1:20% Q1:20%
P2:100% Q2:20%
P3:100% Q3:20%
P4:100% Q4:20%

Lin:50.0% Lout:100.0%
V1:50% F1:1.000
V2:100% F2:0.800
V3:100% F3:0.800
V4:100% F4:0.800

CANCEL

OK

